



DIMENSION4

Location System Config Guide

Version 3.7

Part Number: D4_LSC_3.7_EN

Copyright © 2023, Ubisense Limited 2014 - 2023. All Rights Reserved. You may not reproduce this document in whole or in part without permission in writing from Ubisense at the following address:

Ubisense Limited
St Andrew's House
St Andrew's Road
Cambridge CB4 1DL
United Kingdom

Tel: +44 (0)1223 535170

WWW: <https://www.ubisense.com>

All contents of this document are subject to change without notice and do not represent a commitment on the part of Ubisense. Reasonable effort is made to ensure the accuracy of the information contained in the document. However, due to on-going product improvements and revisions, Ubisense and its subsidiaries do not warrant the accuracy of this information and cannot accept responsibility for errors or omissions that may be contained in this document.

Information in this document is provided in connection with Ubisense products. No license, express or implied to any intellectual property rights is granted by this document.

Ubisense encourages all users of its products to procure all necessary intellectual property licenses required to implement any concepts or applications and does not condone or encourage any intellectual property infringement and disclaims any responsibility related thereto. These intellectual property licenses may differ from country to country and it is the responsibility of those who develop the concepts or applications to be aware of and comply with different national license requirements.

UBISENSE®, the Ubisense motif, SmartSpace® and AngleID® are registered trademarks of Ubisense Ltd. DIMENSION4™ and UB-Tag™ are trademarks of Ubisense Ltd.

Windows® is a registered trademark of Microsoft Corporation in the United States and/or other countries. The other names of actual companies and products mentioned herein are the trademarks of their respective owners.

Contents

Getting Started	1
1.1 Prerequisites	3
Configuring Logging	4
2.1 Adding a Logging Server	4
2.2 Assigning a Logging Server	5
2.2.1 Assigning a Logging Server to a Cell	5
2.2.2 Inheriting a Logging Server	5
2.2.3 Checking that the Logging Services are Running	5
2.3 Retrieving Log Data	5
2.4 Changing a Logging Server	6
Configuring the Cell Hierarchy	7
3.1 Creating a Geometry Cell	8
3.2 Creating a Location Cell	10
3.3 Starting Cell Services	11
3.4 Modifying a Geometry or Location Cell	12
3.5 Deleting a Geometry or Location Cell	13
3.6 Guidelines for Assembly Plants	13
Importing Representations and Adding Background Objects	14
4.1 Supported File Types	14
4.2 Importing Representations	14
4.3 Transforming a Map Representation by Using Reference Points	16
4.4 Defining the Origin	17
4.5 Placing Background Representations and Objects	18
4.5.1 Importing Survey Points	18
Downloading the ubisense_ls_survey_admin tool	19
Using the ubisense_ls_survey_admin tool	19
4.6 Deleting an Object	20
Adding and Placing Devices	21
5.1 Adding and Deleting Devices	21

5.1.1 Adding a Device Using its MAC Address	21
5.1.2 Adding a Device by Scanning its Barcode Label	22
5.1.3 Naming Devices	22
5.1.4 Deleting a Device	23
5.2 Working with Sensor Groups	23
5.2.1 About Sensor Groups	24
5.2.2 Creating Sensor Groups	25
5.2.2.1 Defining a Clipping Region	26
5.2.3 Adding a Sensor to a Group	26
5.2.4 Positioning Sensors	27
5.2.4.1 Estimating the Pitch and Yaw	27
5.2.4.2 Obtaining Sensor Positions	28
5.2.4.3 Positioning the Sensor	29
5.2.5 Removing a Sensor from a Group	29
5.2.6 Unpositioning Sensors	29
5.2.7 Reusing Sensors	30
5.2.7.1 Archiving a sensor	30
5.2.7.2 Reusing a sensor	30
5.2.8 Deleting a Sensor Group	31
5.3 Positioning TDUs	31
Configuring Timing	33
6.1 Timing Sources and Timing Trees	33
6.2 Configuring Timing Sources	34
6.3 Configuring Timing Options for Sensors	34
6.3.1 Receiving Timing through a Timing Cable	34
6.3.2 Receiving Timing from a TDU	35
6.3.3 Configuring Timing Sources for Use with TDUs	35
6.4 Checking and Troubleshooting Timing Trees	36
Sensor Network Configuration	38
7.1 Creating a Search Order	38
7.2 Creating a DNS Configuration	39
7.3 Assigning Network Settings to Devices	40

7.4 Network Statuses	41
7.5 Deleting DNS Configurations and Search Orders	42
Solving Sensor Parameters	43
8.1 Running the Solver for the Correct Sensors	43
8.2 Prerequisites	44
8.3 Running the Solver	45
8.3.1 Start a Solver Run	45
8.3.2 Review and Accept Results	46
8.3.3 Check the Operation	47
8.4 Reviewing Solver Status	48
8.4.1 Sensor Results	49
8.4.2 Sensor Group Summary	49
8.5 Viewing and Modifying Solver Runs	50
Setting up Tag Filters	51
9.1 Creating a Filter	51
9.2 Configuring Height and Speed	52
9.3 Setting the Motion Model	53
9.4 Applying a Filter	53
Configuring 2.4GHz Receivers (discontinued)	55
Viewing the Device Status	56
11.1 Device Statuses	56
11.2 Adding Comments to Devices	57
11.3 Troubleshooting Booting Errors	57
11.4 Rebooting Devices	57
Reviewing Location Events	59
12.1 Getting Location Events	59
12.1.1 Listening in Real Time	59
12.1.2 Retrieving Historical Location Events	59
12.1.3 Filtering Messages	60
12.1.4 Troubleshooting	60
12.2 Reviewing Location Events	61
12.2.1 OK Orientation and Timing Results	62

12.2.2 Poor Orientation and Timing Results	63
12.2.3 Group Arbitration Failures	63
12.3 Importing Location Events	64
12.4 Exporting Location Events	65
Viewing Trace Messages	66
Replacing the Infrastructure	67
14.1 Replacing and Removing a Device	67
14.2 Moving a Sensor or TDU	67
14.3 Replacing a Timing Cable	68
Updating the Device Software and Firmware	69
15.1 Updating the Software Version	69
15.2 Updating the Firmware Version	69
Setting Up Ident Sensors	71
16.1 How Ident Sensors Generate Location Events	71
16.2 Groups	73
16.2.1 Ident Groups	73
16.2.2 Snoop Groups	74
16.3 Configuration Overview	75
16.4 Creating an Ident Group	76
16.4.1 Troubleshooting Ident Groups	76
16.5 Adding an Ident Sensor	77
16.6 Creating a Snoop Group	78
16.7 Configuring Ident Parameters	79
16.8 Adding and Positioning Ident Points	79
16.9 Example Scenario	81
Custom Sensor Properties	83
17.1 Creating Custom Sensor Properties	83
17.2 Adding and Editing Views	84
17.3 Viewing Custom Sensor Properties	84
17.4 Importing Custom Sensor Properties	85
17.5 Exporting Custom Sensor Properties	86

DIMENSION4 support for GPS	87
18.1 Configuring DIMENSION4 sensors to receive GPS	87
18.2 Creating and configuring GPS reference points	88
18.3 Configuring tag type declarations	91
18.4 Viewing generated XYZ positions of the tag	92
18.5 Tracing the tag GPS protocol and calculation	94
18.5.0.1 The ls_sink_gps trace stream	94
18.5.0.2 Message reception from the sensor	94
18.5.0.3 Rejection of duplicate packets	95
18.5.0.4 Flushing filter state when the tag is moving	95
18.5.0.5 Setting up the GPS-XYZ mapping using the reference points	95
18.5.0.6 Rejecting the calculated XYZ if it is too far from the sensor	96
18.5.0.7 Filtering the reading using a median buffer	96
18.5.0.8 Extracting a median value for assertion	96
18.6 Enabling Clipping Regions with GPS Tag Positions	96
18.7 Configuring advanced parameters	97
Setting up DHCP Servers	99
Configuring Battery Usage Monitoring	100

Getting Started

The Location System Config tool (LSC) allows you to configure your D4 RTLS to locate tags in real-time, which involves:

- Setting up logging servers to store the generated data.
- Importing background representations and objects to create a 3D environment of your physical location tracking space.
- Adding and configuring devices including UWB Sensors (sensors) and Timing Distribution Units (TDUs).
- Solving sensor parameters to generate accurate sightings of tags.
- Setting up tag filters.

The LSC contains various tabs that are listed in the order in which you are likely to complete these tasks.

Getting Started

Show all, Show selected
For restricting the number of devices shown in the LSC tool. Click **Show all** to redisplay all devices

Filter by device name or MAC
For restricting the number of devices shown in the LSC tool by inputting all, or part, of a name or MAC address. Can further reduce the **Show Selected** list.

Expand All, Collapse All
Expands or collapses the hierarchy of devices shown in the LSC tool.

Editor
For entering, modifying and deleting configuration data

The screenshot shows the Location System Config (LSC) user interface. On the left is a sidebar with navigation options like 'Cell hierarchy', 'Presentations', and 'Network configuration'. The main area is divided into three sections: a top control bar with 'Show all', 'Show selected', a search filter box, and 'Expand all' buttons; a central 'SENSOR' panel with options to 'Add new device' and 'Create new groups'; and a right-hand 'Hide view options' panel with checkboxes for 'Show background', 'Show reference p', 'Show sensor/TDU', 'Show clipping reg', 'Show coords whe', 'Show timing tree', and 'Show cell extents'. A 'View selected objects on the map' button is at the bottom of the central panel.

Figure 1-1: Location System Config User Interface

1.1 Prerequisites

Before you begin:

- Ensure that some of the sensors, and any TDUs and 2.4GHz Receivers, are installed and connected. When you complete the configuration in LSC, the devices automatically obtain the configuration information they need in order to boot.

For information on installing and connecting devices, see the DIMENSION4 website at <https://www.ubisenseDIMENSION4.com>.

- Ensure that the Location Platform server is connected to the network. You need this in order to set up logging, and add sensors and configure their network settings.
- Obtain a copy of the sensor installation plan, which typically provides the following information:
 - The ways in which sensors must be grouped and organized.
 - The timing configuration, for example which sensors need to be configured as timing sources.
 - The orientation and position of each sensor.



Although the orientation of a sensor can be estimated, the position must be accurate. If the sensor installation plan provides only the estimated positions, ensure that you obtain the accurate X, Y, Z position of each sensor. For best performance we recommend surveying sensor positions using a Total Station.

Configuring Logging

The D4 RTLS generates large amounts of log data, including:

- Event data (tag location information captured by sensors).
- Trace messages about the performance of your D4 RTLS.

For audit and optimization purposes, we recommend that you capture and store log data according to your business policies.

To set up logging:

1. Identify the logging requirements of your D4 RTLS.
2. Determine how to structure your logging system.
3. Configure logging servers, and then assign them to various cells. For information about cells, see [Configuring the Cell Hierarchy](#) on page 7.



Event data is always generated at the Location Cell level, regardless of how you set up your logging servers.

2.1 Adding a Logging Server

Before you add a logging server, ensure that:

- A suitably configured Location Platform is installed on the server
- The logging server has sufficient disk space to store log messages

To determine the required disk space for logging, use the spreadsheet [LoggingDiskRequirements.xlsx](#). The spreadsheet allows you to calculate the required disk space based on the number of tags, tag update rate, and other parameters.

Additional information on configuring logging is provided in *Setting up DIMENSION4 logging at a production site* in the DIMENSION4 website at <https://www.ubisenseDIMENSION4.com>.

To add a logging server:

1. On the **Configure logging** tab, in the lower pane, double-click **<Add server log properties>**.
2. Select the server that you want to add.
3. Set the maximum disk space (in MB) to use on the server.
4. Set the path to the log directory to use on the server.
5. Click **Save**.

The logging server is added. You can now assign it to various cells.

2.2 Assigning a Logging Server

When you assign a logging server, it is inherited through the cell hierarchy:

- The logging server of the Site Cell is inherited by its Geometry Cells and Location Cells.
- The logging server of a Geometry Cell is inherited by its Location Cells.

You can also assign separate logging servers to the Site Cell and each Location Cell.

After a logging server is assigned to one or more cells, it starts storing data.

2.2.1 Assigning a Logging Server to a Cell

To assign a logging server:

1. On the **Configure logging** tab, in the upper pane, expand the cell hierarchy. The cell hierarchy shows the existing Site Cell, Geometry Cells, and Location Cells.
If a cell does not have a logging server assigned, the cell status appears as **<logging disabled>**.
2. To assign a logging server, click to select the cell and then slowly double-click **<logging disabled>**, or press the Enter key.
The **<logging disabled>** status changes to a drop-down list.
3. From the list of available servers, select the logging server that you want to assign.

2.2.2 Inheriting a Logging Server

If you have assigned separate logging servers to various cells, but want to inherit the logging server from a parent cell:

1. Select the cell.
2. From the Server drop-down list, select **<inherit server from parent>**.

2.2.3 Checking that the Logging Services are Running

After assigning a logging server to a cell, you can check logging services – "Logging configuration" and "Logging data" – are running, in the MANAGE SERVICES tab of the Service Manager tool.

2.3 Retrieving Log Data

The log data primarily captures:

- Tag locations, tracked by the sensors.
- Trace messages about the performance of your D4 RTLS.

To retrieve log data, use either the **Review location events** tab as described in [Reviewing Location Events](#) on page 61, or the **View trace messages** tab.

2.4 Changing a Logging Server

You can change a logging server in the D4 RTLS at any time, for example:

- If you need to replace or upgrade the machine on which the logging server is running.
- If you delete a Location Cell, in which case you can optionally remove the log server properties for logging servers that are no longer used.
- If the logging destination, either the server or the server name, has changed.

To replace a logging server in LSC

1. Set up a new logging server as described in [Adding a Logging Server](#) on page 4.
2. If required, archive the logs for today and the previous 3 or 4 days; the number of days depends on your operating environment.
3. Assign the new logging server to the cell.

To remove a logging server from the D4 RTLS


1. On the **Configure logging** tab, select the server that you want to delete, and then press the Delete key.

The server is removed from the list of logging servers.

2. If the server is assigned to one or more cells, reassign a different logging server to the cells, as required.

Configuring the Cell Hierarchy

Setting up a cell hierarchy involves defining the 3-dimensional space within which the tags will be tracked. A valid cell hierarchy contains three different types of cells that are listed in the following table.

Cell	Purpose
Site Cell	The Site Cell represents the entire site that is covered by the D4 RTLS. The Site Cell is created by default when you install the LSC.
Geometry Cell	The Site Cell contains one or more Geometry Cells. A Geometry Cell represents a smaller area within the Site Cell, such as: <ul style="list-style-type: none">• a floor of a building.• a production area.
Location Cell	A Geometry Cell contains one or more Location Cells. A Location Cell represents a particular region or area where sensors are installed (sensor groups), such as: <ul style="list-style-type: none">• a process in a production area.• a phase in the production cycle.• any area where continuous tracking of tagged assets is required. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> In order to allow for continuous tracking of assets, make sure that Location Cells fully cover the areas where tags will be located.</div>

In a valid cell hierarchy:

- All Geometry Cells are contained by the Site Cell.
- A Location Cell is contained by a unique Geometry Cell.
- The Location Cells do not overlap.

Tags are tracked as they move into and out of the areas where sensors are installed. Event information is recorded for each Location Cell and passed up the cell hierarchy, from each Location Cell up to the Site Cell.

3.1 Creating a Geometry Cell




- The Site Cell is created by default when you install the Location System Config tool.
- Ensure that you select a meaningful reference point at your site for the origin of the cell hierarchy.
- We recommend that you provide a meaningful name for each Geometry Cell.

To create a Geometry Cell:

1. Click the **Configure the cell hierarchy** tab.
2. Create a new Geometry Cell by following the onscreen instructions. Using your mouse, add points to create the required extent for the cell – it must cover the area of interest. When you click and drag to add a point, the coordinates of the point are displayed.

Notes:

- When defining the cell extent, you may prefer to work in the **2D** view.
- The Geometry Cell can be any shape. However, we recommend that you create a cell that is reasonably square or rectangular, and that you avoid a long, thin rectangle.
- If there are multiple Geometry Cells, ensure that they *do not* overlap.
- You can display geometry and location cells additional to the cell you are creating by selecting the checkboxes beside their names in the SHOW CELLS list. The additional selected cells are shown as gray rectangles. Use the **Show all** and **Show none** buttons to select or unselect all cells.
- To fine tune the position of a point, click on it and enter the x and y co-ordinates in the editor.



Configuring the Cell Hierarchy

3. Define the top and bottom boundaries of the Geometry Cell to contain the Location Cells (and Sensor Groups).

Field	Description
Top	The height of the cell in meters. Any heights set for the Location Cells (or the Sensor Groups) contained by this Geometry Cell must be equal to or less than this value.
Bottom	The floor height of the cell in meters. Any floor heights set for Location Cells (or the Sensor Groups) contained by this Geometry Cell must be equal to or greater than this floor height.
Snap Grid	Snaps the cell extent to the nearest intersection of lines in the grid, when you drag the points with your mouse.

4. After you have created the cell, you can use the **View** options to check it in either 2D or 3D.
5. Click **Save**.

When you create the Geometry Cell, it will not usually be inside the Site Cell. Follow the onscreen instructions in the **Errors** panel to fix this. The LSC tool automatically fixes the error by enlarging the Site Cell to contain the cell hierarchy.

3.2 Creating a Location Cell



- You can create a Location Cell only if you have set up at least one Geometry Cell.
- We recommend that you provide a meaningful name for each Location Cell.


To create a Location Cell:

1. Click the **Configure the cell hierarchy** tab and expand the Geometry Cell that will contain the new Location Cell.

2. Create a new Location Cell by following the onscreen instructions.

Notes:

- Place the Location Cell extent within a Geometry Cell.
- The Location Cell can be any shape.
- If there are multiple Location Cells, ensure that they *do not* overlap.
- You can display geometry and location cells additional to the cell you are creating by selecting the checkboxes beside their names in the SHOW CELLS list. The additional selected cells are shown as gray rectangles. Use the **Show all** and **Show none** buttons to select or unselect all cells.
- To fine tune the position of a point, click on it and enter the x and y co-ordinates in the editor.



3. Define the top and bottom boundaries of the cell, ensuring that the Location Cell is contained within the Geometry Cell.
4. Save the cell. If there are any errors, the LSC tool displays messages to identify particular problems, and provides options to fix them.

After you have created a cell, you can check it in either 2D or 3D.

3.3 Starting Cell Services

Deploy the cell services for the Site Cell, each Geometry Cell, and each Location Cell:

Configuring the Cell Hierarchy

1. Start the **Service Manager** tool. The **Cells** option lists all the Site Cells, Geometry Cells, and Location Cells that you have created.
2. You can deploy services for either:
 - The entire Site Cell, including all the Geometry Cells and Location Cells that it contains
 - A particular Geometry Cell or Location Cell

After you deploy services for a cell, the status of the cell changes to **Running**.




At this point, you can assign logging servers as described in [Configuring Logging](#) on page 4.

3.4 Modifying a Geometry or Location Cell

To modify an existing Geometry or Location Cell:

1. On the **Configure the cell hierarchy** tab, double-click the cell to display the editor.
2. Modify the shape and/or extent of the cell, as required.
 - You can display geometry and location cells additional to the cell you are editing by selecting the checkboxes beside their names in the SHOW CELLS list. The additional selected cells are shown as gray rectangles. Use the **Show all** and **Show none** buttons to select or unselect all cells.
 - To fine tune the position of a point, click on it and enter the x and y co-ordinates in the editor.



3. Click **Save**.

3.5 Deleting a Geometry or Location Cell

To delete a cell:

1. On the **Configure the cell hierarchy** tab, select the cell.
2. Press the Delete key.
 - **Geometry Cell:** The Geometry Cell and its Location Cells are deleted.
 - **Location Cell:** The Location Cell is deleted.
 - Sensors, Sensor Groups and background objects are not deleted.
3. Using the Service Manager tool, undeploy services for the deleted cells:
 - a. From the Start menu, run **Service Manager 3**.
 - b. In the SERVICES pane, select **All** (the top-level folder).
 - c. Click the CELL column heading in the list of services on the right-hand side of the screen to sort the services by cell. Scroll down to display any services associated with an **Unknown Cell**.
 - d. Select all the services associated with the **Unknown Cell** and click the **Undeploy** button.

3.6 Guidelines for Assembly Plants

When setting up a cell hierarchy for an assembly plant, ensure that you consider load balancing requirements. A few guidelines are as follows:

- Split a plant into Geometry Cells.
- If a production line is made up of parallel bands, ensure that a single band is covered by its own Location Cell.
- If a production line has a very long, continuous section, split the section into multiple Location Cells.

Importing Representations and Adding Background Objects

A representation is a 2D representation or 3D model, such as a map, floor plan, or objects in the physical location tracking environment. For example, you can use a map as a guide when placing sensors and TDUs.

Representations, such as a map, are optional. They are intended to help you with placing sensors. They do not affect the functionality of your D4 RTLS. However, if you want to use representations, you must size and scale them accurately.

Setting up a map and other background objects involves:

1. Importing a background representation and any other additional models that represent various objects from your physical environment.
2. Scaling (resizing) and modifying the alignment and position of each representation, as necessary.
3. Placing these objects as required.



To accurately resize, scale and rotate the map representation of the site, you need to know the X, Y coordinates of two locations at the site. For best results, these locations should have been accurately measured using a Total Station.

4.1 Supported File Types

You can import the following file types:

- Bitmap (.bmp)
- COLLADA (.dae)
- Graphics Interchange Format (.gif)
- JPEG (.jpg and .jpeg)
- OpenSceneGraph (.osg)
- Portable Network Graphics (.png)
- Scalable Vector Graphics (.svg)

4.2 Importing Representations

Importing representations is optional. If required, you can import representations to:

Importing Representations and Adding Background Objects

- Provide a background, such as a floor plan, on which you can place other objects and sensors.
- Represent objects and items, which you can use as a guide when placing sensors.

To import a background representation and any other additional objects:

1. On the **Import representations** tab, import the images of the required background representations and objects.
2. Resize and reposition each representation as required, by modifying the following settings.

To enter a value, click to select the row and then click again to make the box editable.

For 3D images, switch between the different axes using the **TOP VIEW**, **FRONT VIEW**, and **SIDE VIEW** options.


Setting	Enables you to...
Size and Scale	Resize the representation to the required measurements and scale. You can resize representations, including map representations, by using the Reference Points tool. See Transforming a Map Representation by Using Reference Points on page 16.
Origin	Move the origin to the required position in the representation. For information on the importance of the origin for the background image, see Defining the Origin on page 17.
Rotation	Adjust the orientation (in degrees) of the representation using the following options. Yaw: The horizontal angle of the image. Pitch: The vertical angle of the image. Roll: The amount that the image is tilted to one side or the other.

3. If you need to reset the representation to its initial values, click **Reset transformation**.

The settings are saved.

Rotating a Representation

To rotate an image, click and then drag the arrows clockwise or anticlockwise:



Additional Features for Positioning Representations

To position images correctly, you can also use the view options that are listed in the following table.

Feature	Enables you to...
Show axis lines	View the X, Y and Z axes, so that you can position the image at the required coordinates.
Show scale	View the actual height and width of the image.
Show bounding boxes	View the boundaries or the full extent of the image.
Show reference points	For details, see Transforming a Map Representation by Using Reference Points on page 16.

Exporting Representations

To copy the image to a local directory, click the **Export** button.

4.3 Transforming a Map Representation by Using Reference Points

You can resize, scale, rotate and set the origin of the map representation in one step if you know the X, Y coordinates of two locations at the site. This will produce the most accurate results if the locations are as far apart as possible.




Figure 4-1: Transforming a Representation Based on the X, Y Coordinates of Two Known Locations

Importing Representations and Adding Background Objects

You resize, scale and rotate the map representation using the **Reference Points** tool:



The **Reference Points** tool has a direction – reversing the order of Point 1 (left end) and Point 2 (right end) of the reference line will rotate the map representation.

To transform a map representation based on known coordinates:

1. On the **Import representations** tab, select the map representation.
2. In the workspace, click the **TOP VIEW** option.
3. Click to turn on **Show reference points**.
4. Position the two ends of the reference line on the two locations.
5. Enter the X, Y coordinates of the first location in the **Point 1 X**, **Point 1 Y** fields.
6. Enter the X, Y coordinates of the second location in the **Point 2 X**, **Point 2 Y** fields.

The representation is then transformed. The transformation sets the correct values for:

- size, as shown in the **Size X, Y** fields
- offset from the origin, as shown in the **Origin X, Y** fields
- scale factor, as shown in the **Scaling X, Y** fields
- rotation, as shown in the **Yaw** field


4.4 Defining the Origin

Before you place images, ensure that you define the origin for:

- **Background representations:** The origin marks the 0,0,0 coordinates that identifies the point, relative to which the sensor positions were measured. [Transforming a Map Representation by Using Reference Points](#) on page 16 describes how to resize, scale, rotate and set the origin of the background representation in one step.
- **Other images:** You can use the origin to mark the central point of an object, which can make it easier for you to place objects by using absolute coordinates.

To mark the origin of an image:

1. On the **Import representations** tab, select the required image.
2. Click and drag the origin to the required position in the image, as shown in the following figure:



The updated X,Y,Z coordinates are displayed on the left.

3. Adjust the origin using the **Origin X**, **Origin Y** and **Origin Z** fields.

4.5 Placing Background Representations and Objects

After you have imported and adjusted the required images, you can place these objects as required in the **Add background objects** tab.

In addition to images you have imported, listed on the left-hand side of the **Add background objects** tab are Ubisense-supplied representations for:

- GPS reference points, described in *Creating and configuring GPS reference points* on page 88
- Ident points, described in *Adding and Positioning Ident Points* on page 79
- Survey points, which can be used when solving sensor parameters, described in *Solving Sensor Parameters* on page 43

These Ubisense-supplied representations can be placed in the same way as any other representations. Survey points can also be imported using the [ubisense_ls_survey_admin](#) tool.

To place objects:

1. Click the **Add background objects** tab. All the background representations and images that you have imported are listed at the top.
2. Select and drag the background representation to the screen. The background object is listed at the bottom—double-click the object to display an editor in which you can adjust the location and orientation of the background representation.
3. Select and drag additional objects to the screen.
4. Following the onscreen instructions, place and position the additional objects on the background representation, as required.

4.5.1 Importing Survey Points

There are two methods for adding survey points:

Importing Representations and Adding Background Objects

- Like other background objects, in the **Add background objects** tab, you can drag Survey point reference objects onto the map
- You can use the `ubisense_ls_survey_admin` command-line tool to import named survey points and their positions

Downloading the `ubisense_ls_survey_admin` tool

To get the `ubisense_ls_survey_admin` tool, run Application Manager, open the DOWNLOADABLES task, and expand **Location system /Administration tools**. Select `ubisense_ls_survey_admin` and click **Download selected items**. Optionally, change the download destination directory. Click **Start download**.

Using the `ubisense_ls_survey_admin` tool

The tool can import named survey points individually from the command-line or from a file of survey points. In either case, each point must be specified on its own line in the format "**NAME**",**"X"**,**"Y"**,**"Z"**.


For example, take a file `survey-locations.csv` with the following survey points:

```
"SP1", "1", "12", "0.5"  
"SP2", "10", "12", "0.5"  
"SP3", "15", "12", "0.5"  
"SP4", "21", "11", "0.5"
```

Running the tool in **import** mode sets the specified positions.

```
C:\>ubisense_ls_survey_admin import < C:\Ubisense\survey-locations.csv  
creating SP1 at [1,12,0.5]  
creating SP2 at [10,12,0.5]  
creating SP3 at [15,12,0.5]  
creating SP4 at [21,11,0.5]  
set 4 survey point positions
```

You can see the positioned survey points by opening the **Add background objects** tab in LSC:



If you want to replace all current survey points with new ones, run the tool with the **replace-all** option:

```
ubisense_ls_survey_admin import < new-locations.csv --replace-all
```

You can also collect the positions of survey points currently in DIMENSION4 by running the tool in **export** mode.

4.6 Deleting an Object

To delete an object, and its representation:

1. Click the **Add background objects** tab. The **BACKGROUND OBJECT** section lists all the representations that you have added and placed.
2. Select the object that you want to delete, press the Delete key, and click **Delete** to confirm the deletion.

You can also double-click the object on the map and, in the editor, select **Remove object** and click **Save**.

The object is removed. However, the representation is still retained in the D4 RTLS.

3. To delete the representation:
 - a. On the **Import representations** tab, locate and select the image that you want to delete.
 - b. Press the Delete key and click **Delete** to confirm.

The representation is removed from your D4 RTLS.

Adding and Placing Devices

You can add DIMENSION4 sensors, Timing Distribution Units (TDUs) and the discontinued 2.4GHz Receivers to your D4 RTLS.

Adding and placing devices involves:

- Adding each device by specifying its MAC address.
- Creating one or more sensor groups to group the devices logically, and adding each device to the appropriate group.

Device	Details
Sensors	Create the required groups, and enter the location of each sensor. You do not need to enter the orientation of the sensors—the Solver will calculate this for you.
TDU	Automatically added to its own group. Enter the location.
2.4GHz Receiver	Automatically added to its own group. Enter the location.

- Adding sensors to the appropriate groups.
- Positioning sensors.

5.1 Adding and Deleting Devices

You can add a sensor or TDU to the D4 RTLS by either:

- Typing its MAC address.
- Scanning its MAC address from the barcode label.

The D4 RTLS supports TDUs that have a MAC address starting with 00:11:CE:E4.

You can also add a discontinued 2.4GHz Receiver by typing in its MAC address. The D4 RTLS supports 2.4GHz Receivers that have a MAC address starting with 00:11:CE:D5.

5.1.1 Adding a Device Using its MAC Address

To add a device by using its MAC address:

1. On the **Place devices** tab, add the required device. To add multiple devices, type the MAC address of each device on a separate line.
LSC automatically detects the type of device and places it in the correct group.

2. Save the MAC addresses that you have typed.

The device(s) appear on the following lists:

- **Ungrouped:** The *sensors* currently do not belong to any group.
- **Unpositioned:** The devices, whether sensors, TDUs or 2.4GHz Receivers do not have a location.

5.1.2 Adding a Device by Scanning its Barcode Label

To add a device by scanning its MAC address from the barcode label on its back panel, you require a 1D Barcode Scanner.

To add a device by scanning its barcode label:

1. Connect the Barcode Scanner to your computer.
2. On the **Place devices** tab, double-click **<Add new device>**.

Make sure that the cursor is displayed in the box.

3. Using the Barcode Scanner, scan the MAC address barcode label of the device.
4. The MAC address appears on the list of devices to be added.
5. Save the address that you have scanned.

The device(s) appear on the following lists:

- **Ungrouped:** The *sensors* currently do not belong to any group.
- **Unpositioned:** The devices, whether sensors, TDUs or 2.4GHz Receivers do not have a location.

5.1.3 Naming Devices

The devices listed on the **Place devices** tab are listed by name if the name is configured, otherwise they are listed by MAC address.

To enter the name of each device, double-click the MAC address to display the editor.



A meaningful name can help you to identify the sensor more easily, particularly in large-scale installations.

We recommend that you add the last two HEX pairs from the MAC address to the sensor name. For example, **PAINTSHOP_S1_01:54**, which represents the first sensor that belongs to the **PAINTSHOP** area and has a MAC address **00:11:CE:D4:01:54**.

5.1.4 Deleting a Device

You can only delete a device that is ungrouped.

To delete a device:

1. On the **Place devices** tab, select the device that you want to delete from the **Ungrouped** list, and then press the Delete key. The LSC tool prompts you to confirm that you want to delete the sensor.
2. Click **Delete**.

The device is deleted. It no longer generates location data or distributes timing.



In production systems *earlier than version 3.6*, it is recommended that you do **not** delete devices. Always swap them, using the **Replace infrastructure** tab, as described in [Replacing and Removing a Device](#) on page 67.

5.2 Working with Sensor Groups

In a D4 RTLS, the entire location tracking area is covered by one or more Sensor Groups. Sensors that belong to the same group can exchange data to locate a tag. Sensors from different groups cannot exchange data.

The size and number of groups that you must create depends on the requirements defined in your sensor installation plan.

Typically, groups are created depending on:

- The size of the location tracking area. A small area might require one group with a small number of sensors, whereas a larger area might require multiple groups and more sensors.
- The way in which you want to track your objects. For example, if objects are moving along a line, you can create overlapping groups, so that the sensors can track objects as they move from one area to another.

5.2.1 About Sensor Groups

A Sensor Group can cover multiple rooms. Sensors can belong to one or more groups.

An example Location Cell with three sensor groups, is shown in the following figure.




Figure 5-1: Sensor Groups

In the example:

- Group A and Group B are adjacent to each other (and overlap). Sensors AB1 and AB2 belong to both Group A and Group B. Therefore, these two sensors can exchange data with the other sensors from both Group A and Group B.
- Sensors A1, A2, B1, and B2 are not shared. Therefore, they cannot exchange any data between Groups A and B.
- Group C is completely independent and does not share any sensors or exchange data with Group A and Group B.

A sensor group can overlap location cells but the results can be confusing when reviewing events, because sensors send data to the location cell they are in and the choice of sensor for a tag does not depend on the location of the tag—so event data from a tag in cell A may go to cell B.

You can define a clipping region for a Sensor Group if you are only interested in the location events that are generated when tags are inside the area covered by the clipping region.

If required, you can also define a zone around the clipping region, called the *snap distance*. If a tag is detected inside the *snap distance*, it is considered to be inside a Sensor Group. Therefore, if a tag enters this zone, sensors can locate the tag even if it is not fully within the group.

As a sensor group represents a 3-dimensional space, you can configure both horizontal snap distance and vertical snap distance for your sensor group. The following figure shows an example for horizontal snap distance.




Figure 5-2: Horizontal Snap Distance

5.2.2 Creating Sensor Groups

To create a sensor group:

1. Click the **Place devices** tab.
2. Create a new sensor group. To create multiple sensor groups at the same time, type the name of each sensor group, one on each line of the box.
3. Click **Save**.

The new groups appear in the list of existing groups.

5.2.2.1 Defining a Clipping Region

You can optionally define a 2.5D clipping region for each group.

1. Double-click the group.
2. Following the onscreen instructions, add points to define the 2D extent of the clipping region.

When you click and drag to add a point, the coordinates of the point are displayed. Use this information to place the clipping region within the Location Cell, allowing also for the snap distance that is in addition to the extent.

Notes:

- The clipping region can be any shape.
 - If you want to share a sensor between groups that have a clipping region, then the clipping regions should overlap.
 - If you have set up a background representation, you can use this as a guide when defining the 2D extent of the clipping regions.
 - To view coordinates and additional features such as background representations, click **Show view options**.
3. Specify the height (top and bottom) of the clipping region in meters—this must be contained within the height of the Location Cell.

The floor of the clipping region must match the actual height of the floor in your physical environment. This floor height is used as a reference to specify the height range for tag filters, as described in [Configuring Height and Speed](#) on page 52.

4. Optionally, specify the horizontal and vertical snap distances.

5.2.3 Adding a Sensor to a Group

Each sensor must belong to at least one group. You can also add a sensor to multiple groups if you need to track the movement of a tag from an area covered by one Sensor Group into an area covered by another group.

To add a sensor to a group:

1. Click the **Place devices** tab.
2. Do one of the following:
 - If the sensor does not belong to any group, it appears on the list of **Ungrouped** sensors. Select the sensor and then drag it into the required group.
 - If the sensor already belongs to a group and you want to share it with another group, press the Shift key, and drag and drop the sensor from one group to another group. The sensor is listed in both groups.

5.2.4 Positioning Sensors

Positioning a sensor in a group involves:

1. Specifying the precise X, Y, and Z coordinates of the sensor.
2. Specifying the approximate pitch and yaw angles of the sensor.

This information is used to calculate tag positions.

5.2.4.1 Estimating the Pitch and Yaw

When placing a sensor, you should specify the approximate pitch and yaw of the sensor. These values are then accurately measured and overridden when you run the Solver, as described in [Solving Sensor Parameters](#) on page 43.

Pitch

Pitch is the vertical angle of the sensor. Examples of a sensor positioned at a pitch of -41° and -55° , are shown in the following figure.




Figure 5-3: Sensor Positioned at Different Pitch Angles

Yaw

Yaw is the horizontal angle of the sensor, shown in the following figure.



Figure 5-4: Yaw, Pitch, and Roll of a Sensor

5.2.4.2 Obtaining Sensor Positions

To calculate the position of a tag, you require the precise X, Y, Z coordinates of each sensor that belongs to the group.

These coordinates are measured with a Total Station and recorded after the sensors are installed.

To calculate the X, Y, Z coordinates of a sensor:

1. Define a coordinate system.
 - a. In your location tracking site, pick a point on the floor (origin) from which you can measure the coordinates.
 - b. Decide which horizontal direction you want to use as the positive X-axis. Facing in this direction, the positive Y-axis is to your left, and the positive Z-axis is upwards.
2. Following the instructions supplied with your Total Station, measure the position of the fiducial mark on the front panel of the sensor.

Ensure that you:

- Measure both horizontal and vertical offsets to the sensor.
 - Survey the positions of the sensor to an accuracy of better than 5 cms. If the surveyed positions are accurate, the Solver (part of Location System Config) returns more reliable sensor positions.
3. Note down the coordinates for the X, Y, and Z axes, for example, add them to the Sensor Installation Plan.

5.2.4.3 Positioning the Sensor



Unpositioned sensors cannot generate location data. To generate location data:

- The coordinates of the sensor must be inside a Location Cell.
- The sensor must belong to a Sensor Group.

Sensors that do not have a location appear on the list of **Unpositioned** sensors (even if they already belong to one or more groups).

To position a sensor:

1. On the **Place devices** tab, double-click the MAC address or name of the sensor.
2. Define its position by specifying the location, yaw, and pitch.

Field	Value
Location	Type the X, Y, and Z coordinates with the values that have been calculated with a Total Station. Note that: <ul style="list-style-type: none"> • The coordinates must be inside a Location Cell. • You can drag the sensor from the Unpositioned list onto the map.
Yaw and Pitch	Type the estimated horizontal and vertical angles at which the sensor has been mounted or enter 0. For more information, see Estimating the Pitch and Yaw on page 27.

5.2.5 Removing a Sensor from a Group

To remove a sensor from a group:

1. Expand the group from which you want to remove the sensor.
2. Select the sensor, and then press the Delete key.
3. The sensor is removed from the group.

Note that the sensor appears on the list of **Ungrouped** sensors only if it does not belong to any other group.

5.2.6 Unpositioning Sensors



If you have already run the Solver then you must use the **Replace infrastructure** tab to invalidate the orientation results of any sensors that you unposition. You must do this before rerunning the Solver. See [Replacing the Infrastructure](#) on page 67.

To unposition a sensor:

1. On the **Place devices** tab, double-click the MAC address or name of the sensor that you want to unposition.
2. Select the **Unset sensor position** checkbox.
3. Save the settings.

The sensor still belongs to the group but it no longer has any coordinates, and therefore appears on the list of **Unpositioned** sensors.

4. You can now reposition the sensor as required.

5.2.7 Reusing Sensors

The following steps take you through how to reuse previously-used sensors in your D4 system. There are two parts to the process:

- Archiving the sensor to remove it from its current group and take it out of use
- Adding the sensor to its new group and reconfiguring it

5.2.7.1 Archiving a sensor

1. Create a sensor group for archived sensors.

In the **Place devices** tab, create a sensor group for all physically removed sensors, for example called "Storage".

See [Adding and Placing Devices](#) on page 21 for additional information on working with sensors and groups.

2. Move the sensor to the archived sensors group.

In the **Place devices** tab, locate the sensor to be archived, select it and drag it from its current group to the archived group.

You can add a comment to the sensor if required in the **View sensor status** tab.

3. Unset the position of the sensor so it is no longer visible.

In the **Place devices** tab, double-click the MAC address or name of the sensor, select the **Unset sensor position** checkbox, and click **Save**.

The sensor is now listed in the archive group and as **Unpositioned**.

4. Assert that the sensor has moved.

In the **Replace infrastructure** tab, double-click **<Assert that a sensor has moved>**, type the MAC address of the sensor and click **Save**.

5.2.7.2 Reusing a sensor

1. If you added a comment to the archived sensor, clear the comment.

in the **View sensor status** tab, double-click the sensor, delete the text, and click **Save**.

2. Rename the sensor, if required.

In the **Place devices** tab, double-click the MAC address or name of the sensor, type the new name and click **Save**.

3. Move the sensor to a new group and set the new position.

In the **Place devices** tab, locate the sensor in the archived group, select it and drag it to its new group. Then double-click the MAC address or name of the sensor to open the editor where you can enter its location.

4. Configure a custom network configuration for the sensor, if required.

At this point, the sensor should be working with DHCP, but you can assign custom settings if necessary. To do this, in the **Sensor network configuration** tab, double-click the MAC address or name of the sensor, enter the required settings, and click **Save**.

See [Assigning Network Settings to Devices](#) on page 40 for information on valid combinations of settings.

5. Reboot the sensor and confirm it is running.

On the **View sensor status** tab, select the sensor and click **Reboot**. If the device's status is **Running**, it has booted successfully.

6. Initiate the solving procedure for the sensor on the **Solve sensor parameters** tab.

See [Solving Sensor Parameters](#) on page 43 for further information.

5.2.8 Deleting a Sensor Group

To delete a Sensor Group:

1. On the **Place devices** tab, select the group that you want to delete, and then press the Delete key. The LSC tool prompts you to confirm that you want to delete the group.
2. Click **Delete**.

The Sensor Group is deleted. If the sensors do not belong to any other group, they appear on the list of **Ungrouped** sensors.

5.3 Positioning TDUs

You must set the position of TDUs as this ensures that they are displayed in the correct location on the background map.

A TDU does not need to be positioned in the same Location Cell as its sensors. You do not have to specify the orientation of a TDU as TDUs do not locate tags.

To position a TDU:

Adding and Placing Devices

1. On the **Place devices** tab, expand the TDU group.
2. Do one of the following:
 - Double-click the TDU that you want to position, and then type its X, Y, Z co-ordinates.
 - Drag the TDU to the map.

Ensure that you position the TDU within the extent of a Location Cell.

Configuring Timing

Sensors use timing signals to record the precise time at which they detect a UWB pulse from a tag and then generate TDOAs that are used for identifying the tag location.

Configuring timing involves:

1. Setting up one or more sensors as timing sources.
2. Defining how other sensors receive timing signals.

6.1 Timing Sources and Timing Trees

The timing signal is always generated by a sensor that has been designated as a timing source. The timing source is at the root of a timing cable tree, and provides synchronization signals to all the downstream or recipient sensors in that tree.

When two sensors are connected with a timing cable, the upstream (supplying) sensor controls the timing signal and transmits its MAC address to the downstream (receiving) sensor. The sensors therefore detect the topology of the timing tree automatically.

Ideally all the sensors in a Sensor Group belong to the same timing tree.

If necessary, a group can have multiple timing sources and timing trees, as shown in the following figure.




Figure 6-1: Multiple Timing Trees in the Same Group

The figure shows an example sensor group that has six sensors and two separate timing trees:

- Sensors 2 and 3 receive timing signals from Timing Source 1. They are synchronized with each other and generate TDOAs.
- Sensors 5 and 6 receive timing signals from Timing Source 2. They are synchronized with each other and generate TDOAs.



You do not need to synchronize sensors from different Sensor Groups.

6.2 Configuring Timing Sources

The sensor installation plan defines the timing sources and cabling for each group. Each group can have multiple timing sources and timing trees.

To set up a sensor as a timing source:

1. On the **Configure timing** tab, identify the sensor that must be configured as the timing source.
By default, all sensors are configured to receive timing signals through a cable.
2. Select the sensor that must be configured as a timing source. From the **Timing** drop-down menu, select **Timing source**.
3. Reboot the sensor, as described in *Rebooting Devices* on page 57.



You must reboot the sensor whenever you change the timing source.

The timing status of the sensor is updated. The sensor now only generates timing signals, which can be used by other sensors.

6.3 Configuring Timing Options for Sensors

Sensors can receive timing either through an Ethernet cable or a timing cable.

6.3.1 Receiving Timing through a Timing Cable

By default, a sensor is configured to receive timing through a timing cable.

On the **Configure timing** tab, choose the **Receive from cable** option from the drop-down list if either:

- The sensor has been daisy-chained, where it receives timing signals from another sensor that is connected to the timing source.
- The sensor receives timing signals directly from the timing source.

6.3.2 Receiving Timing from a TDU

If you are using a TDU to distribute combined network and timing signals, you must change the timing configuration for the sensors.

To do this, on the **Configure timing** tab, change the timing status to **Receive from ethernet**.

6.3.3 Configuring Timing Sources for Use with TDUs

You can use a sensor to distribute combined network and timing signals through the Ethernet cable (connected to the Ethernet (PoE) port on the sensor) as shown in the following figure.




Figure 6-2: Hardware Configuration for Distributing Timing on the Ethernet Port

Configuring Timing

For this setup, change the timing configuration as follows:

1. On the **Change sensor parameters** tab, select the sensor to use as the timing source.
2. Navigate to the **Sensor > Physical > Timing > Allow Ethernet Output** parameter.

The parameter has the following values:

- *False*: the sensor is configured for timing input only on the Ethernet port.
 - *True*: the sensor is configured to send timing output on the Ethernet port, if it does not receive timing from this port.
3. Double-click **Allow Ethernet Output** and set the parameter as required:
 - To configure the sensor for both timing input and output, select the checkbox.
 - To configure the sensor for timing input only, clear the checkbox.
 4. Click **Save**.

6.4 Checking and Troubleshooting Timing Trees

i You can check and troubleshoot timing trees only after the sensors have booted.

After you have set up timing sources and defined timing options for the other sensors in the group, check the timing trees to see how the timing signals are distributed.

On the **Place devices** tab, click **Show view options**, and then select **Show timing tree**.

Red arrows, which indicate timing signals, are shown on the sensor group:




Figure 6-3: Sensor Group Showing the Timing Tree

The directions of the arrows show how the timing signals are distributed. Review the timing tree carefully to check that the timing signals are distributed, as expected.

If the arrows fail to appear or do not appear as you expected, check for any obvious issues, for example:

- Check that you have set up correct timing sources and cabling options for sensors.
- Check that the physical cables have been connected to the correct ports on the sensors, as described in the DIMENSION4 website at <https://www.ubisenseDIMENSION4.com>.

Sensor Network Configuration

All devices in your D4 RTLS are connected by means of network cables and require a network connection to exchange data. They must also be able to connect to a Location Platform server in order to obtain configuration information for booting.

By default, each device receives its IP address, subnet mask, and default gateway from a DHCP server. (If you do not have a DHCP server, see [Setting Up DHCP Servers](#) on the Ubisense Documentation Portal for further information and an example configuration.)

Alternatively, you can configure a device to connect to the Location Platform server by assigning:

- A static IP address, subnet mask, and default gateway.
- A DNS configuration, which can contain up to four DNS server IP addresses and up to four suffixes to use.
- A particular search order, which contains a sequence of different methods, such as a simple domain name, fully qualified domain name, IP address, or broadcast, which the device can use to contact the Location Platform server.

From DIMENSION4 3.7 SP1 onwards, sensors will boot reliably on networks where the Ethernet switches are configured with Spanning Tree Protocol (STP) and 802.1x / MAB. For information on how the sensor boot process relates to 802.1x / MAB and STP and how to configure recommended timeouts to support sensors using DHCP on a typical switch see [Booting DIMENSION4 under STP and 802.1x](#) on the Ubisense Documentation Portal.

7.1 Creating a Search Order

The search methods that you can use are listed in the following table.

Search Method	Device connects to the network by...
Simple domain name	Using a domain name that resolves to an IP address known to the DNS server.
Fully-qualified domain name	Using a domain name that specifies its exact location in the tree hierarchy of the Domain Name System (DNS).
IP Address	Using the IP address of the Location Platform server.
Broadcast	Searching for any available Location Platform server on the same sub network.

To set up a search order:

1. On the **Sensor network configuration** tab, add a new search order, ensuring that you provide a unique name for the search order.
2. Add the required search methods in the order that they should be used.

3. Review the details that you have typed.



It is not possible to modify a search order after you save it. To modify an existing search order, you must delete it and then create a new search order with the required settings.

4. Save the search order. The new search order appears on the list of **Search Orders**. You can add the search order to the required devices.

7.2 Creating a DNS Configuration

To create a new DNS configuration:

1. On the **Sensor network configuration** tab, create a new DNS configuration.

For example, name it **ubisenseconfig**.

2. Add up to four DNS IP addresses or DNS Suffixes or both, as required.
3. Review the details you have typed.

It is not possible to modify a DNS configuration after you save it. To modify an existing DNS configuration, delete it and then create a new configuration.

4. Save the DNS configuration.
5. Assign the DNS configuration to the required devices. See [Assigning Network Settings to Devices](#) on page 40.



Each device will accept the DNS configuration only if it can validate the configuration by contacting a Location Platform server. If, after approximately ten minutes, it cannot validate the configuration, the device will revert back to the default network configuration. See [Network Statuses](#) on page 41.

7.3 Assigning Network Settings to Devices

All devices that currently do not have any custom network configuration are listed in the **Default** group. These devices use DHCP settings by default.

To assign custom network settings to a sensor or TDU:

1. On the **Sensor network configuration** tab, select the required device.
2. The device can support a valid combination of settings, as listed in the following table.

IP Address	Subnet Mask	Default Gateway	DNS Config	Search Order
-	-	-	-	✓
✓	✓	-	-	-
✓	✓	-	-	✓
✓	✓	-	✓	-
✓	✓	-	✓	✓
✓	✓	✓	-	-
✓	✓	✓	-	✓
✓	✓	✓	✓	✓

For additional information, see [Notes](#) on page 41.

3. Save your settings.

The device is listed under the **pending validation** group until the static IP settings and/or DNS configuration are validated. If the settings are valid, the device is listed under the **valid** group.

Notes

If you left any fields blank, the device connects to the server as described in the following table.

If you did not specify...	Behavior
IP address and subnet mask	The device connects to the Location Platform server by using DHCP.
Default gateway	<ul style="list-style-type: none"> • If you have not specified an IP address and subnet mask, the device obtains the gateway IP address by means of DHCP. • If you have specified an IP address and subnet mask, the device will not have a gateway IP address. The device can only contact the Location Platform server in its subnet.
DNS configuration	<ul style="list-style-type: none"> • If you have not specified an IP address and subnet mask, the device obtains the DNS configuration by means of DHCP. • If you have specified an IP address and subnet mask, the device will not perform any DNS queries.
Search order	The device uses the default Ubisense search order.

7.4 Network Statuses

After you have assigned network settings to a sensor or TDU, it appears under one of the network status groups that are listed in the following table.

Network Status Group	Description
Custom (valid)	The device has successfully validated the network settings.
Custom (pending validation)	The network settings are awaiting validation from the device.
Custom (invalid)	The device could not validate the network settings.
Default	The device is using the default network configuration (DHCP). Custom network settings have not been specified.

7.5 Deleting DNS Configurations and Search Orders

You can only delete DNS configurations and search orders that are currently not used by any device.

To delete an existing DNS configuration or search order:

1. Identify the devices that are currently using the specific DNS configuration or search order.
Remove the DNS configuration or search order from the network settings of each device.
2. From the list of **DNS Configurations**, select the configuration that you want to delete, and then press the Delete key.

The DNS configuration is removed from the list.

Solving Sensor Parameters

After you have booted the sensors successfully, you can calculate the orientation and timing for the sensors by running the Solver. During this process, the Solver calculates:

- The yaw and pitch for each sensor, to determine the correct angle at which the sensors receive signals from a tag.
- The cable delay or the time required for the timing signal to reach each sensor. This delay must be calculated to determine the TDOA.

The D4 RTLS uses these values to identify the location of tags.



- Before running the Solver, we recommend reviewing events on the **Review location events** tab in order to check that events are occurring.
- You can copy a tag ID from the timeline (by selecting and pressing Ctrl+C) and paste it into the **Solve sensor parameters** tab.

To run the Solver:

1. Place a tag in a known position.

You can enter the tag's location into the Solver either by inputting the tag's coordinates or by choosing a survey point at which the tag is located.

2. Run the Solver to calculate the yaw, pitch, and cable delay values for the sensors that can see the tag and which are in the same timing tree.

You can run the Solver multiple times for the same sensors. Each solver run captures statistics from hundreds of readings. The D4 RTLS uses the best results based on the lowest standard deviation.

The Solver results of individual sensors affect the group summary. Therefore, you must also run the Solver after you have:

- Physically moved a sensor and recorded the move on the **Replace infrastructure** tab.
- Replaced a timing cable and recorded the swap on the **Replace infrastructure** tab.

8.1 Running the Solver for the Correct Sensors

The Solver calculates the sensor orientation and cable delay values based on the specific position of a reference tag.

When you run the Solver, it lists all the sensors that can detect signals from a reference tag. If one or more sensors only have a partial line of sight to the tag (see the following example), the Solver might return inaccurate results for those sensors. Therefore, ensure that you run the Solver only for those sensors that can directly sight the tag.

An example sensor group that contains sensors with different orientations, is shown below.




Figure 8-1: Choosing Sensors when Running Solver

In this example, the sensor parameters are solved with the tag at two different positions, P1 and P2. The sensors can sight the tag as summarized in the following table.

Tag Position	Direct Line of Sight	Partial Line of Sight
P1	Sensor A, Sensor B, and Sensor F	Sensor C and Sensor D
P2	Sensor C, Sensor D, and Sensor E	Sensor A and Sensor F

If you solve parameters with the tag at P1, the Solver lists Sensors C and D, even though they can only sight the tags partially. If you include these sensors in the Solver run, the orientation results for these two sensors will be inaccurate.

To obtain accurate results for Sensors C and D:

- Exclude these sensors from the Solver run when the tag is at P1.
- Solve parameters for these sensors when the tag is at P2.

8.2 Prerequisites

Before running the Solver, ensure that you have:

- Configured logging, as described in [Configuring Logging](#) on page 4. This enables the Solver to obtain data from sensors.

- Added sensors to groups and positioned them, as described in [Positioning Sensors](#) on page 27. This enables the Solver to calculate orientations and cable delays.
- Configured timing and set the appropriate sensors as timing sources, as described in [Configuring Timing Sources](#) on page 34.

8.3 Running the Solver



You can run the Solver multiple times for the same sensors. The D4 RTLS uses the best results based on the properties of the received signals.

Before you begin:

- Place a tag in a position at which the sensors can sight it.
- Ensure that you have the tag ID and the position of the tag in meters.

You can also indicate the tag's position by placing it a survey point. See [ImportingSurveyPoints](#) for information on adding survey points to the map.

To calculate accurate orientation and timing values for each sensor that can see the tag:

1. Run the Solver.
2. Review, accept, and save the required results.
3. Check that the tag is being accurately located, and then close the solver run.

8.3.1 Start a Solver Run

To start a Solver run:

1. On the **Solve sensor parameters** tab, click **Solve**.

Notes:

- If you have not yet run the Solver or if a sensor from a group does not have any result (for example, it cannot detect the tag), then the group summary appears as **Incomplete**.
- To view the Solver status of individual sensors from the group, expand the group. Sensors that do not have any results show:
 - The estimated pitch and yaw, if you have provided these values.
 - A timing result of **Not done**.

Solving Sensor Parameters

2. Either:

- Type the complete tag ID and the X, Y, Z coordinates (in meters) of the tag that you have placed, and then click **Start**.

or

- Select **Use survey point**, choose a survey point from the dropdown, and then click **Start**. The survey point's X, Y, Z coordinates are filled automatically.

Notes:

- It can take some time for all sensors to appear on the screen.
- Results are only displayed when you select the checkboxes for one or more of the sensors listed in the **Store results** area.
- The Solver captures statistics from hundreds of readings for the selected sensors. The values displayed on the screen are continuously updated based on new readings. The values stabilize when the readings are consistent.

3. The next step is to review and accept the results.

8.3.2 Review and Accept Results

After running the Solver, the **Solve sensor parameters** tab shows results for the selected sensors, in a three-column layout, as shown in the following example:




Figure 8-2: Solver Window

To review and accept results:

1. In the first column, the Solver lists all the sensors that can detect UWB signals from the tag. Select only those sensors that have a direct line of sight to the tag (see *Running the Solver for the Correct Sensors* on page 43).
2. In the second column, the Solver lists the calculated pitch and yaw for each sensor. Select the results that you want to use.

Notes:

- Even if the standard deviation is low, accept the results only if they correspond to the physical orientation of the sensors.
 - If the results of a sensor are consistently poor:
 - Solve parameters for the sensor by placing a tag in a different measured position.
 - Check and adjust the physical orientation of the sensor, if necessary.
 - Check if there are any obstructions that might affect the ability of the sensor to sight the tag.
3. In the third column, the Solver lists the cable delay between sensor pairs—*by default all checkboxes in this column are selected for you.*

Notes:

- The results for a sensor pair do not appear if a timing signal path from the sensors to the timing source does not exist.
 - If the results are not generated or are consistently poor:
 - Check that you have set up correct timing sources and cabling options for sensors.
 - Check that the physical cables have been connected to the correct ports on the sensors, as described in the DIMENSION4 website at <https://www.ubisenseDIMENSION4.com>.
4. When the readings are stable, save the results.



The results displayed on the screen are updated even after you save your solver run. If you click **Save** again, the new results replace the existing values in your solver run.

5. The next step is to check the results of the operation.

8.3.3 Check the Operation

After saving the solver run, check its outcome.

The following screenshot shows an example of sensors with OK results.




Figure 8-3: Sensors with OK Orientation Results

Orientation Results

The color of the sensor shows the orientation results for that sensor:

- Green: the orientation results are acceptable (OK).
- Yellow: the orientation results are poor.
- Grey: there are no orientation results.

The TDOAs and AOAs show that the filter is using the results when:

- The color of the TDOAs changes to blue. The TDOAs also intersect at the tag location.
- The color of the AOAs is green.

For information on setting up filters, see [Setting up Tag Filters](#) on page 51.

Timing Results


To check the timing results, close the solver run, and review the information shown in the summary table.

8.4 Reviewing Solver Status

The Solver records the sensor orientation and timing (cable delay values) for the group as a whole and also individual sensors from the group. The result of an individual sensor affects the overall result of its group. For example, if a sensor does not have a result, the summary of the entire group appears as **Incomplete**.


8.4.1 Sensor Results

The possible Solver results for sensors are summarized in the following table.

Sensor Summary	Description
OK	The results are acceptable, as they have a low standard deviation.
OK (Partition N)	This indicates that timing has been solved for separate sets of sensors within a group (i.e. the partitions) but that there is not enough information to calculate timing between these sets. This will lead to inability to compute TDOA for sightings involving sensors from the different sets. Resolving this requires running the solver for a tag located in sight of some sensors from both sets.
Not done	The sensor does not have any Solver results yet.
Poor	<p>The results have a high standard deviation and therefore may or may not be acceptable.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;">  For information on resolving poor results, see Review and Accept Results on page 46. </div>

8.4.2 Sensor Group Summary

The possible statuses for sensor groups are summarized in the following table.

Group summary	Description
OK	All sensors from the group have acceptable results.
Incomplete	<p>A sensor group has this status when:</p> <ul style="list-style-type: none"> • One or more sensors from the group do not have a result. • Timing has been solved for separate sets of sensors within a group, but with insufficient information to calculate timing between these sets. • All the results have been rejected.
Poor	<p>The results for one or more sensors from the group are poor.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;">  For information on resolving poor results, see Review and Accept Results on page 46. </div>

8.5 Viewing and Modifying Solver Runs

You can modify existing Solver runs to accept or reject individual values that were calculated for a particular sensor.

To view and modify a solver run:

1. On the **Solve sensor parameters** tab, select the required sensor group or sensor. All solver runs that apply to the selected sensor group or sensor are listed.
2. To view or modify a solver run, double-click the required solver run.
The solver run lists the yaw, pitch, and cable delay values for all sensors that were included in that run.
3. Accept or reject the values as required.



To reject a result, clear the **Accept?** checkbox.

4. Close the solver run.
The status of the sensor and its group are updated.

Notes

- The overall pitch, yaw, and cable delay values of a sensor are calculated from multiple solver runs. When you modify a solver run, the overall values are recalculated.
- If sufficient readings or solver runs are not available for determining the pitch, yaw, and cable delay values of a sensor:
 - The sensor shows the estimated yaw and pitch and/or a timing result of **Not done**.
 - The orientation and/or timing status of the sensor group changes to **Incomplete**.

Setting up Tag Filters

A tag filter is a set of rules and conditions that you can configure to define, for example, the height at which the tag is likely to be found, and the speed at which the tag is likely to move. These filters are used by sensors to sight and track tags.

To configure and apply a tag filter:

1. Create a filter.
2. Configure the required parameters, including the height, speed, and model type for the filter.
3. Optionally, experiment with different values to obtain better locations, by using command-line tools—see the advanced documentation described below.
4. Apply the filter to either a tag, a tag type, or a range of tags.



This section explains how to define basic filter parameters that you can use with, for example, car tags and tool tags.

Additional information about configuring tag filters, including **Flags** and **Limits**, is given in Setting up Tag Filters in the DIMENSION4 website at <https://www.ubisenseDIMENSION4.com>.



9.1 Creating a Filter

You can set up a filter for either a particular tag, a tag type, or a range of tags. To configure different filter settings for different sets of tags, ensure that you create a separate filter for each set of tags.

To create a filter, on the **Set up tag filters** tab, add a new filter and then configure filter parameters to define how the tags must be tracked.

9.2 Configuring Height and Speed

For each filter that you create, configure the height and speed parameters that are listed in the following table.


Parameter	Description
Default Height	<p>This height is used during initialization, if the true height of the tag cannot be determined.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;">  If you are not sure which value to use, specify a value that lies half way between the maximum height and minimum height. </div>
Horizontal Speed	<p>The maximum speed at which the tag can move, before the calculated position starts to lag. We recommend that you set this value to slightly higher than the fastest speed at which the tag is likely to move.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;">  If you set this to a very high value, the reported location jumps too quickly in response to new measurements. </div>
Maximum Height	<p>The maximum height that the tag is likely to reach. Any sightings of a tag that are above this value will be rejected.</p>
Minimum Height	<p>The minimum height that the tag is likely to reach. Any sightings of a tag that are below this value will be rejected.</p>

Height

- Although the maximum and minimum heights do not have to be very accurate, ensure that they are approximately the same as the actual heights at which the tags are used. For example, for tool tags that are carried by people:
 - 0.5 m (knee height).
 - 1.0 m (waist height).
 - 1.5 m (shoulder height).
- If the sensor groups have a clipping region, ensure that the height that you specify is in relation to the floor of the clipping region of the sensor group that detects the tag. If you have set the height of sensors and the clipping regions to the correct absolute heights, the same filter parameters will work, for example, if the tag is used on two different floors of the same building.

Speed

Use an estimated value for the speed at which the tag is likely to move. A common value that you can use for speed is 2.5 m/s (5.5 mph or 9 kph), which is slow jogging speed.

 If your site requires precise locations, you can experiment by using various values to identify the values that provide the most reliable results.

9.3 Setting the Motion Model

The **Model Type** parameter specifies the motion model, which is used for extrapolating the movement of the tag.



In most situations, you can set this parameter to **2 (Stationary)**.

Option	Description
1 (Planar)	The tag position moves in a fixed-height horizontal plane.
2 (Stationary)	The tag can move horizontally and vertically, with a minimum and maximum height limitation. Always select this option for all regular location tracking scenarios.

9.4 Applying a Filter

You can apply a filter to either:

- A tag *range*, by specifying the filter to be assigned to a range of tag IDs.
- A tag *type*, by specifying the filter to be assigned to a tag type (this takes precedence over a tag range).
- A particular tag, by specifying the filter to be assigned to a specific tag ID (this takes precedence over a tag type).

Tag ranges must not overlap. However a tag range that is a subset of another tag range is supported, as shown in the following example.

Filter Range	Supported (Yes/ No)
Filter 1 range: 00:11:CE:00:00:00:01:00 to 00:11:CE:00:00:00:01:FF Filter 2 range: 00:11:CE:00:00:00:01:C0 to 00:11:CE:00:00:00:02:40	No. The tag ranges overlap from 01:C0 to 01:FF.
Filter 1 range: 00:11:CE:00:00:00:01:00 to 00:11:CE:00:00:00:01:FF Filter 2 range: 00:11:CE:00:00:00:01:C0 to 00:11:CE:00:00:00:01:DD	Yes. Tags in the smaller range use Filter 2 . Tags in the larger range (excluding tags in the smaller range) use Filter 1 .

Setting up Tag Filters

To apply a filter to a tag, tag type or tag range:

1. On the **Set up tag filters** tab, do one of the following:
 - To apply a filter to a set of tags, double-click **<Add new tag range>**. Specify the range of tag IDs, in hexadecimal format.
 - To create a new tag type and apply a filter to it, double-click **<Add new tag type>**. Specify the name of the tag type, and (optionally) the name of a different tag type to use as a template for how tag battery usage is monitored for this new tag type.
 - To apply a filter to a particular tag, double-click **<Add new tag>**. Specify the tag ID, in hexadecimal format.



You can find the tag ID on its case.

2. Apply the required filter.
3. Save your changes.

The sensors start tracking the tag, the set of tags, or tag types according to the filter settings.



You can change the filter assigned to a tag, tag type or tag range by slowly double-clicking on a current filter to display a menu of available filters to choose from.

Checking Filters

To check that the filters are working as expected:

1. Review events, as described in [Reviewing Location Events](#) on page 61.
2. Check the performance of filters by comparing new events with previous events.

You can also use command-line tools for this.

Configuring 2.4GHz Receivers (discontinued)

2.4GHz Receivers are no longer supplied by Ubisense. From DIMENSION4 version 3.5 onwards, certain DIMENSION4 sensors can receive GPS signals from tags, and associated DIMENSION4 support services can be configured to handle these signals. Hence dedicated 2.4GHz Receivers have been discontinued. See [DIMENSION4 support for GPS](#) on page 87 for information on current provision for tags with 2.4 GHz radio. You can access details on configuring the discontinued 2.4GHz Receivers at [Ubisense 2.4GHz Receivers](#) on the Ubisense Documentation Portal.

Viewing the Device Status

Sensors and TDUs that are connected to the network, and receiving power through Power-over-Ethernet (PoE), will have *Running* status if you have:

- Created the required Geometry Cells and Location Cells.
- Positioned the devices within Location Cells.
- Configured network and timing for the devices.

The actual status of the sensors in the different Location Cells will differ depending on the completeness of the configuration.

To view the status of a sensor or TDU, click the **View sensor status** tab.

11.1 Device Statuses

A device that has *Running* status has booted successfully.

The following statuses indicate that you have configured the device but there is a specific problem that you need to resolve:

Status	Description
Last seen booting	The device was rebooted at the specified date and time. This means one of the following: <ul style="list-style-type: none"> • The device is either in the process of booting. • The device has failed to boot successfully. See Troubleshooting Booting Errors on page 57.
No timing signal	The device has booted successfully, but is not receiving a timing signal.

These statuses indicate a more fundamental problem:

Status	Description
Last seen...	With the exception of <i>Last seen booting</i> , there is problem preventing the system from reporting the current status. For example, there may be no network connection.
No geometry cell No location cell	The device is not located in a geometry cell or location cell so it cannot obtain its configuration settings from the server. It will continue to reboot until it has obtained its configuration.
Unknown	The device may not be connected to the network.

Notes on the View sensor status tab:

- The **Status Age** indicates the duration for which the device has been in its current status.
- You can sort sensors by clicking the column headings.
- You can group sensors by using the **Group by** option.
- You can optionally add comments to individual devices or sets of devices.
- A command-line tool `ubisense_ls_sensor_status` can be used to print a similar table of sensor statuses, optionally filtered by the sensors' last reboot times. This can be downloaded from the Ubisense Application Manager in Ubisense > Location system > Administration tools.

11.2 Adding Comments to Devices

You can add a comment to one or more devices listed on the **View sensor status** tab.

To add a comment to a single device—double-click the device to open the editor.

To add a comment to several devices:

1. Press the Shift or Ctrl keys and then click the required devices.
2. Click **Edit comment**.

11.3 Troubleshooting Booting Errors

For information about error codes, see the Boot Process documentation supplied with the DIMENSION4 website at <https://www.ubisenseDIMENSION4.com>—sensors and TDUs have the same operating statuses and error codes.

LED Error Codes and Timing Trees

In a timing tree, the upstream sensor distributes timing to the downstream sensors. If the upstream sensor is not working, the downstream sensors do not receive timing and the LEDs will flash green/orange (notice that this is *not* an LED error code). Therefore, when troubleshooting any booting errors, first examine the timing tree for any potential problems.

11.4 Rebooting Devices

To reboot sensors and TDUs:

1. On the **View sensor status** tab, select the device that you want to reboot. To reboot multiple devices: press the Shift or Ctrl keys and then click the required devices.
2. Click **Reboot**.

The status of the device first changes to **Rebooting** then, after the device is booted successfully, the status changes to **Running**.

When handling a large number of sensors, it is useful to group the sensors first. For example, to reboot sensors in a sensor group and then observe their status:

1. Group the sensors by **Group**.
2. Select the sensors in the **Group**, and then click **Show selected**.
3. Click **Reboot**.
4. Group the sensors by **Status**, and then click **Expand all**. The progress summary of only those sensors that you have rebooted is then displayed.
5. When you have finished, click **Show all**.

Reviewing Location Events

You can check the location of tags by reviewing either:

- Historical events, which show the location history of one or more tags.
- Real-time events, which show the current location of one or more tags.

12.1 Getting Location Events

12.1.1 Listening in Real Time

When you listen in real time, you can review the events as and when they are generated by the sensors.

To view the location of tags in real time:

1. On the **Review location events** tab, clear the display if required.
2. Click **Get events**.
Notice the maximum number of real-time events to display. We recommend that you do not normally change this.
3. Select the **Listen in real time** option.
4. Select the Location Cell.
5. Click **Start listening**.
6. Monitor events as they occur. See [Reviewing Location Events](#) on page 61.
7. When you have finished, click **Stop listening**.
8. You can now:
 - Save the events by exporting them to an event file. See [Exporting Location Events](#) on page 65.
 - Filter the events to show just a subset of the events. See [Filtering Messages](#) on page 60.

12.1.2 Retrieving Historical Location Events

To view historical location events:

1. On the **Review location events** tab, if necessary click **Clear**.
2. Click **Get events**.
3. Enter the maximum number of events to retrieve.
4. Select the **Use last** or **Enter timespan** options.
5. Select the Location Cell.

6. Click **Retrieve Messages**.

After all the location events within the timespan are retrieved, the button changes back to **Get events**.

7. Review the events that have been retrieved.

8. You can now:

- Retrieve events for other Location Cells, and LSC will merge them into the timeline, in chronological order.
- Load events by importing them from an event file.
- Filter the events to show just a subset of the events.
- Export the events in the timeline.

12.1.3 Filtering Messages

To filter location events that you have retrieved whether real-time or historical:

1. Click **Get events**.
2. In the **Times** section, select **Filter messages that have already been retrieved**.
3. In the **Filters** section, enter a Tag ID, or multiple tag IDs each on a new line.

You can also paste in a previously-copied tag ID by clicking in the **Tag id(s)** input box and pressing CTRL+V.

You can also set up advanced filter controls if necessary. To do this, click **Switch to advanced filter controls** and then follow the onscreen instructions.

4. Click **Filter Messages**.

You can now review the filtered messages.

12.1.4 Troubleshooting

If no event data is displayed, check that the machine on which LSC is running is listening on the correct port or network interface card (NIC)—the correct NIC is the one that connects via the network to the Location Platform server. If the incorrect NIC is being used, the top line on Events page shows that the IP address is **0.0.0.0: <port>**.

To obtain the IP address of the NIC that LSC is currently using: on the **Review location events** tab, start listening in real time. The IP address is shown in the top left of the tab.

If necessary, you can set the correct IP address of the NIC in the Windows registry:

1. In the Windows Registry Editor, go to Computer > HKEY_LOCAL_MACHINE > SOFTWARE > Wow6432Node > Ubisense 2.1 > Platform > Config.
2. Add a new registry entry (String Value) called **platform_interface**.
3. Set the value of the entry to the IP address (for example, 10.42.55.66) of the NIC connected to the Location Platform server.

4. Restart the Location Platform services.
5. Restart the LSC.

12.2 Reviewing Location Events



Events are generated by sensors if logging is enabled, the sensors are configured correctly, and you have placed a tag that can be seen by the sensors.

To review location events, scroll through the timeline using the horizontal scroll bar. You can also:

- Press the Left or Right Arrow keys to move the timeline by 1
- Press PgUp or PgDn to move the timeline by 10
- Press Home to move the timeline to the start
- Press End to move the timeline to the end
- Press Up arrow or Down arrow to move the timeline to the next or previous event for the current tag
- Hold Ctrl in combination with other keys to move the timeline to valid events only
- Hold Ctrl+Shift in combination with other keys to move the timeline to invalid events only
- Jump to a specific event by typing a valid event number
- Type a string *S*, where *S* contains characters from the set [0123456789abcdef], to move the timeline to that event number if it is valid, or to the first event found with a tag whose ID, excluding colons, contains *S*.

Viewing an individual tag trajectory

Several features are available to help you focus on a particular tag trail you are interested in.

- To display events relating to a specific tag, you can copy a tag number from the timeline by pressing Ctrl+C, clicking **Get events** and then pasting the tag ID into the simple filter.
- To select an event near to a particular point on the map, hold down Alt and then double-click on the location you are interested in.
- To pan the map to the current event in the timeline, press the spacebar (the timeline must have the focus for this to work).
- If the tag trail you are trying to view is hard to see against the background, you can use the bracket keys '[' and ']' to cycle through different colors to improve the tag trail's visibility (the map or timeline must have the focus for this to work).

12.2.1 OK Orientation and Timing Results

A sensor will generate events by using the measurements shown in the following screen shot.




Figure 12-1: Events Generated by Sensors with OK Solver Results

For these sensors:

- The TDOAs are blue and the TDOAs intersect at the tag location.
- The AOAs are green.

If you have chosen to review events for multiple tags, the red dot on the screen moves from one location to the other, indicating the individual location of each tag.

i Additional information on how a location event was calculated is shown in the bottom right pane. Click a sensor to see all the pairs involving this sensor, and the measurements. The map will be updated to show only the TDOAs for the selected sensor.

12.2.2 Poor Orientation and Timing Results

A sensor with results that are poor, or not done, can still sight tags and generate events based on the estimated sensor orientations that you might have provided. However, some of the TDOAs are rejected.

Events of this type are shown in the following screen shot.




Figure 12-2: Events Generated by Sensors with Poor Solver Results

In this situation:

- The TDOAs are in amber.
- Some of the AOA's are red, which indicate that they are being rejected.

i This may also mean that the event is the result of a reflection rather than a problem with the Solver run.

12.2.3 Group Arbitration Failures

Pairs of events are colored red when all of the following conditions apply:

- Tags are identical
- Sequence numbers are identical

Reviewing Location Events

- Locations are both marked OK
- Timestamps are within 1 second of each other

This is because more than one sensor group is generating a valid location for a single tag event, which is an error. The correct behavior would be that the sensors communicate and determine one location event to be valid, and any others to be "superseded by other group".

In addition to the red highlight on events in the timeline, you can:

- Identify the group that generated a measurement by finding the group name in the event
- See the group's clipping region, if you have some clipping regions defined and have checked **Show clipping regions** in the view options




Figure 12-3: Events Highlighted due to Arbitration Failure

12.3 Importing Location Events

You can import location events from saved event files, for diagnostic purposes.



You can load events from multiple cells. The events are then sorted by time received and you can use this information to 'follow' a tag through the site.

To import location events:

1. On the **Review location events** tab, click **Import**.
2. Open the required location events file (**.ubievents** file).



Do not increase the number of events to import above the displayed maximum. Your PC may run out of memory if you do so.

3. Click **Import**.

The location events from the events file are displayed on the screen.

12.4 Exporting Location Events

You can export location events to store the location history of a tag for diagnostic purposes.

To export location events:

1. On the **Review location events** tab, click **Get events**.
2. Retrieve the required location events, as described in [Getting Location Events](#) on page 59.
3. Click **Export**, and then save the location events as a **.ubievents** file.

Viewing Trace Messages

Trace messages provide information about the performance of your D4 RTLS. These are described in detail in [DIMENSION4 trace messages](#).

Replacing the Infrastructure

After you have configured your D4 RTLS, you may need to perform a number of ongoing maintenance tasks, including:

- Replacing sensors and TDUs.
- Moving sensors and TDUs.
- Replacing timing cables.



The Solver keeps track of all the solver runs and how these were used for calculating sensor properties. If you make any changes to the physical infrastructure after you have saved any solver runs, you must:

1. Invalidate the old solver results.
2. Rerun the Solver.

Periodically, you may also need to update the software and firmware versions of sensors and TDUs.

14.1 Replacing and Removing a Device



When you replace a sensor, the existing orientation results continue to be used, even though they may not be correct for the new sensor.

To change the MAC address of a sensor or TDU that you have replaced or removed:

1. On the **Replace infrastructure** tab, double-click **<Swap devices>**.
2. Type the MAC addresses of the old and new devices.
3. Save your changes.

You can now rerun the Solver.

LSC keeps a record of all devices that have been swapped. You do not have to delete any of these records.

14.2 Moving a Sensor or TDU



When you move a sensor, the existing orientation results continue to be used, even though they may not be correct for the sensor in its new location. You must therefore assert that you have moved the device before rerunning the Solver.

Replacing the Infrastructure

To assert that you have moved the device:

1. On the **Replace infrastructure** tab, double-click **<Assert that a sensor has moved>**.
2. Type the MAC address of the sensor that you have moved and click **Save**.

You can now rerun the Solver for the sensor as described in [Solving Sensor Parameters](#) on page 43.

14.3 Replacing a Timing Cable



When you replace a timing cable, the existing timing results for all the sensors that use the cable in their timing route continue to be used, even though these results may not be valid. You must therefore assert that you have changed the cable before rerunning the Solver.

To record that a cable has been changed:

1. On the **Replace infrastructure** tab, double-click **<Swap cable>**.
2. Type the MAC addresses of the sensors that are connected by the cable.

You can now rerun the Solver.

Updating the Device Software and Firmware



Firmware and Software updates where servers use secondary IP addresses

When DIMENSION4 sensors request a file while flashing their firmware and software, they check the identity of the server that responded to the request by looking at the from address in the response packet. When a request is made on a secondary IP address, the response may sometimes come from the primary IP address, causing this identity check to fail and the packet to be discarded. To support servers that use secondary IP addresses, from version 3.7 SP1 and above, there is a global configuration parameter '**tftp_server_addr_list**' (default value "") which can be assigned a comma-separated list of all the server IP addresses. During firmware and software updating, the from address of the response is checked against each of these addresses, and the packet will be retained if it matches any of them.

15.1 Updating the Software Version

This step is optional. However, we recommend that you keep the software version up to date in order to avoid overloading the network when rebooting many sensors.

To update the software version:

1. On the **Sensor software/firmware** tab, in the upper pane, review the software versions:
 - **Intended version:** The latest software version to which you should update the device.
 - **Flashed version:** The current flashed version of the device.
2. If the Flashed and Intended versions of a device are different, select the device and then, in the upper pane, click **Request Update**.

During the upgrade process, the status of the sensor briefly changes to **Flash Update Pending**. After the upgrade is complete, the sensor shows the new software version.

3. Reboot the sensors as described in [Rebooting Devices](#) on page 57.

15.2 Updating the Firmware Version

To update the firmware version:

1. On the **Sensor software/firmware** tab, in the lower pane, review the firmware versions:
 - **Intended version:** The latest firmware version to which you can update the device.
 - **Flashed version:** The current firmware version of the device.

Updating the Device Software and Firmware

2. If the Flashed and Intended firmware versions of a device are different, select the device and then, in the lower pane, click **Request Update**.

During the upgrade process, the status of the sensor briefly changes to **Flash Update Pending**. After the upgrade is complete, the sensor shows the new firmware version.

3. Reboot the sensors as described in [Rebooting Devices](#) on page 57.

Setting Up Ident Sensors

UWB sensors produce a location event by sharing data with other sensors in a group. In contrast, an Ident sensor produces the location of a tag from a single AOA, without any timing synchronization.

You can use *standard Ident sensors* if you simply want to determine whether or not a tagged object is inside a certain area, for example, if a car is inside a particular work area such as a **Test** or **Rework Bay**. Ident sensors can also be used for tag association and disassociation, where an object is located in an area that is remote from the UWB sensors.

You can use *enhanced Ident* functionality to detect the presence of tagged objects at one or more defined points in space by using Ident sensors in conjunction with *Ident points*. For example, with one Ident point you can detect one or more tags at a particular location. Alternatively, by defining an exclusion factor, you can configure an Ident point that only ever contains one tag at a time. (Note that exclusion works on a per-sensor basis. That is sensor A will only put one tag at ident point I, and sensor B will only put one tag at ident point I, but the two sensors may each simultaneously put two different tags at that ident point.)

Using two Ident points with an Ident sensor would enable you to detect a fast-moving tagged object and its direction of travel, for instance when passing through a gate.

You can use an Ident sensor either on its own, or in conjunction with other Ident and/or non-Ident sensors.



This section explains how to configure Ident sensors using the standard parameters supplied with the software.

16.1 How Ident Sensors Generate Location Events

Standard Ident Sensors

A standard Ident sensor generates a valid location when:

1. It receives a signal from the tag and the signal strength is above the configured **Power Threshold** (see [Configuring Ident Parameters](#) on page 79).
2. The AOA from the Ident sensor to the tag intersects with the height of the tag, which is determined by the Ident parameter **Tag Height** (see [Configuring Ident Parameters](#) on page 79).

The following figure shows an example of a valid location.

Setting Up Ident Sensors




Figure 16-1: Valid Location Generated by an Ident Sensor

Invalid Locations

If the AOA does not intersect with the clipping region, the location event is reported as *Invalid* with the message *Discarded by clipping region*.




Figure 16-2: Location is Reported as Invalid

Enhanced Ident Sensors

An enhanced Ident sensor generates a valid location when:

1. An Ident point exists within the 3D clipping region of the Ident sensor's group.
2. It receives a signal from the tag and the signal strength is above the configured **Power Threshold** (see *Configuring Ident Parameters* on page 79).
3. The tag's location is within the inclusion range for the Ident point.

If a valid location is generated, the tag's location is put at the location of the relevant Ident point.




Figure 16-3: Valid Location Generated by an Enhanced Ident Sensor

16.2 Groups

Ident sensors can either work individually or in conjunction with other Ident and/or non-Ident sensors.

16.2.1 Ident Groups

Regardless of whether an Ident sensor works individually or with other sensors, you must first add it to an Ident group.

The following rules apply to Ident sensors and groups:

- An Ident sensor can only belong to one Ident group.
- An Ident group can contain several Ident sensors. Factors such as the size of the tracking area and whether or not sensors have an uninterrupted line of sight to the tag (i.e., the sensors can see the tag clearly without any obstructions) determine the number of sensors in an Ident group.

Setting Up Ident Sensors

- An Ident group with standard functionality detects the presence of tagged objects within its 2D clipping region whilst an enhanced Ident group detects tags near Ident points within its 3D clipping region.
- A D4 RTLS can contain several Ident groups.
- Ident groups and non-Ident groups can co-exist in the same D4 RTLS.
- To use Ident sensors in conjunction with non-Ident sensors, you must add the respective Ident groups to a Snoop Group.

16.2.2 Snoop Groups

If an Ident sensor is located close to other non-Ident sensors, *both* the Ident sensor and non-Ident sensors generate different locations at the same time, causing the tag location to jump. The Snoop group suppresses unwanted location events by acting as arbitrator when there are tag sightings generated by multiple sensors. It ensures that if an Ident sensor receives the strongest signal, then only that sensor generates a location event. Snoop groups can contain both standard Ident groups and enhanced Ident groups.

The following example shows how a Snoop group arbitrates between the tag sightings for tags T1 and T2.




Figure 16-4: Example of a Snoop Group Arbitrating Between Tag Sightings

In the above example of a Snoop group:

Tag	Sensor	Result
T1	Ident sensor C receives a stronger signal than: <ul style="list-style-type: none"> • Ident sensors A and B • Any of the non-Ident sensors 	<p>If there are multiple Ident sensors within the same Ident group, only the sensor that receives the strongest signal will generate a location. Therefore, Ident sensor C can generate a location event for tag T1.</p> <p>The reported location is at the intersection of the AOA with the clipping region of the Ident group.</p>
T2	Non-Ident sensor S4 receives the strongest signal.	The non-Ident sensors in the Sensor group contribute to the location event recorded for tag T2.

16.3 Configuration Overview

An *Ident sensor* is a UWB sensor configured to produce a location of a tag from a single AOA that intersects with a 2D clipping region.

Configuring an Ident sensor involves:

1. Creating an Ident group, if you do not have one already.
2. Adding the sensor to the Ident group.
3. Optionally, creating a Snoop group in scenarios where you want to arbitrate between the readings generated by multiple sensor groups that are located close to each other.
4. Configuring Ident parameters including the **Tag Height** and **Power Threshold**.

An *enhanced Ident sensor* is a UWB sensor configured to produce a location of a tag from a single AOA in proximity with an Ident point that is located in a 3D clipping area. In addition to the steps described above, configuring an enhanced Ident sensor requires the positioning of one or more Ident points within the clipping region of the sensor's Ident group (see [Adding and Positioning Ident Points](#) on page 79).

The configuration steps are described in detail in the next few sections.

16.4 Creating an Ident Group

1. On the **Place devices** tab, create a new sensor group.
2. Enter the following details, and then click **Save**.

Option	Description
Name	A name for the group. The text (<i>ident group</i>) is displayed next to the name.
Make these ident group(s)	Select this checkbox to create the group(s) as Ident groups.

The Ident group appears on the list of existing groups.

3. Double-click the Ident group to edit its properties.
 - a. Draw the boundaries of the clipping region to constrain the location of any tags sighted by the Ident sensor(s) in this Ident group.

Notes:

- To generate valid locations, you must define a clipping region.
 - The clipping region defines the horizontal bounds of the area where the tag is tracked. For a standard Ident group, the height of the 2D clipping region from the base of the location cell is defined by the parameter **Tag Height** (see [Configuring Ident Parameters](#) on page 79). For an enhanced Ident group, you define a top and bottom for the 3D space of the clipping area.
 - The clipping region should be big enough to capture all expected locations of the tag. We recommend that you use an additional margin to the actual area that you want to cover.
- b. Define the tag height for a Standard Ident Group. Select **Use fixed tab height** to set the height of the clipping region (and hence the intercept height). You can also set this on the **Configure ident parameters** tab (see [Configuring Ident Parameters](#) on page 79).

or

Select **Use ident points** to configure an Enhanced Ident Group and specify the height (top and bottom) of the clipping region in meters—this must be contained within the height of the Location Cell.

4. Click **Save**.

16.4.1 Troubleshooting Ident Groups

Occasionally, Ident Groups may not behave as expected. This section answers some of the questions about unexpected behavior of Ident Groups.

Why is my Normal Ident Group displaying settings for an Enhanced Ident Group in the Configure ident parameters tab?

If a Normal Ident Group happens to have an Ident Point exactly on its clipping plane, it will be shown as if it is an Enhanced Ident Group in the **Configure ident parameters** tab. In the unlikely event that this happens, the workaround is to move the Ident Point or the clipping plane height slightly.

What happens if my Enhanced Ident Group doesn't contain an Ident Point?

An Ident Group will behave as Enhanced Ident Group (placing the tag at an Ident point) only if the clipping polygon contains an Ident Point. If there is no Ident Point, the group will behave as a Normal Ident Group (placing the tag at the intersection of the AOA with the clipping plane: half-height between top/bottom of clipping polygon). This happens regardless of whether **Use fixed tag height** or **Use ident points** is selected for the group in the **Place devices** tab.

What can I do if an Ident sensor detects a signal from a tag but fails to extract valid angle data from it?

In some cases a sensor may detect a signal from a tag but fail to extract valid angle data from it. Using the **Assume Boresight** ident configuration option allows an Ident group to be configured in a way that allows the group to assert a tag location, at an Ident point, when an event is received, when the angle cannot be determined. When enabled, invalid angle data from an Ident sensor is translated into the pair of valid angles (0,0), and this can then be used in conjunction with fixed height ident or ident points in order to generate a valid sighting.

The **Assume Boresight** parameter can be enabled in the Group/Ident section of the **Change all parameters** tab.

16.5 Adding an Ident Sensor

1. On the **Place devices** tab, add the sensor by using either its MAC Address or barcode label.
2. Add the sensor to an Ident group by dragging and dropping the sensor into the group. The text (*ident sensor*) is displayed next to the name.



Because an Ident sensor cannot be in more than one group, you *cannot* drag it from one group to another while holding down the Shift key.

3. Position the sensor on the map.

The sensor is now identified as an Ident sensor and the text (*ident sensor*) is displayed next to the sensor name or MAC address.

Optionally, you can now change the power threshold for the Ident sensor, as described in [Configuring Ident Parameters](#) on page 79.

16.6 Creating a Snoop Group

You can either create a new group to use as a Snoop group, or can use an existing Sensor group.

1. If the group that you need does not exist already, on the **Place devices** tab, create a new Sensor group. Ensure that you do *not* select the **Make these ident group(s)** checkbox.
2. On the **Configure ident parameters** tab, assign the new or existing group (as a Snoop group) to the Ident groups.
3. Click **Save**.

For Ident groups that do not have a Snoop group, the **Snoop Group** column displays *<default>*.

Notes:

- To check if the Snoop group is working as expected, review the event logs. Check that the location event shows the MAC address of the Ident sensor as source of the AOA. If the location event is generated by non-Ident sensors, the source of the AOA shows a minimum of two sensors.
- If the Snoop group is no longer required, go to the **Configure ident parameters** tab, and then unassign the group. The group no longer gives first preference to the Ident sensor, even if it receives the strongest signal from the tag.

16.7 Configuring Ident Parameters

You can use the **Configure ident parameters** tab to view or configure the following parameters for one or more Ident groups and the Ident sensors that belong to them.

Option	Description
Snoop Group	The Snoop group that is configured for the Ident group. For Ident groups without a Snoop group, this column displays <i><default></i> . You can assign or change the Snoop group by double-clicking the Ident group and choosing from the list in the editor.
Tag Height (Standard Ident Groups)	The fixed height of the tag (in meters), which defines the height of the clipping region. For Standard Ident Groups, you can view the clipping region and change the tag height on the Place devices tab. See Creating an Ident Group on page 76. N/A is displayed for Enhanced Ident Groups.
Ident Points (Enhanced Ident Groups)	Ident points associated with an Enhanced Ident Group identified by their X, Y, Z positions. For an Enhanced Ident Group, all Ident Points that are located within the group's clipping area are listed here and are in the group. See Adding and Positioning Ident Points on page 79 for information on positioning Ident Points and Creating an Ident Group on page 76 for information on creating an Enhanced Ident Group's clipping area.
Power Threshold	The received UWB signal strength above which a location event is generated. We recommend that you do not set the power threshold higher than 1.7. To set it back to the default value, in the editor, select the Reset power threshold to default checkbox.

16.8 Adding and Positioning Ident Points

In the **Add background objects** tab, you add Ident points by positioning instances of the Ident point object.

An Ident point representation is supplied by Ubisense: you do not need to import a representation for this purpose.

The following rules apply to Ident points and groups:

- An Ident point can only belong to enhanced Ident groups.
- An Ident point belongs to an enhanced Ident group when it is positioned within the clipping region of the group.
- An enhanced Ident group can contain several Ident points.

Setting Up Ident Sensors

- An Ident point can belong to more than one Ident group if the clipping regions of the groups overlap. This allows you to configure Ident points that might have complex obstructions, using more than one sensor.

To place an Ident point:

1. Click the **Add background objects** tab. The Ident point object is listed under **Reference Objects**.
2. Select and drag the Ident point reference object to the screen. The Ident point object is listed at the bottom identified by its X, Y, Z coordinates and orientation (usually [1,0,0,0])—double-click the object to display an editor in which you can adjust its location and orientation.
3. If you have already created sensor groups with clipping regions, you can see which clipping regions you are placing the Ident point in by clicking **Show view options** and then clicking **Show clipping regions**.




Figure 16-5: Example of Ident point positioning

16.9 Example Scenario

This example usage scenario shows you can set up Ident and non-Ident sensors together to track location events.

The following graphic shows a car plant finishing area that contains rework bays with obstructions, which do not allow non-Ident sensors to see the tags.




Figure 16-6: Location Tracking Using a Combination of Ident and non-Ident Sensors

The area is covered completely with non-Ident sensors, which are positioned high-up to provide general tracking capabilities in open areas and aisles. However, the rework bays have heavy obstructions that block these sensors.

Therefore, additional Ident sensors are placed at defined positions inside the bays.

- Sensors Id1, Id2, and Id3 belong to Ident Group 1.
- Sensors Id4 and Id5 belong to Ident Group 2.
- Non-Ident sensors S1-S8 belong to the non-Ident Group.

Setting Up Ident Sensors

- Ident Group 1 and Ident Group 2 are associated with the non-Ident Group, which functions as a Snoop group.

When an Ident sensor receives the strongest signal from the tag (when the car is in a bay), the non-Ident sensors are ignored. The Ident sensor which is the closest to the tag generates the location.

Note that you could add all Ident sensors to Ident Group 1, but splitting them makes the design clearer.

Custom Sensor Properties

Custom sensor properties provide a method of storing custom parameters for sensors and TDUs beyond the properties provided as standard in the Ubisense dataset, for example to store additional information about sensor locations or unusual configurations. This enables you to maintain all information relevant to your DIMENSION4 sensors in a single location, and with the ability to export this to other sources.

Custom properties are added to the dataset using the `ubisense_ls_sensor_properties_admin` tool, and can be of the type `bool`, `choice`, `double`, `int`, `string`, `time` or `timespan`. After custom properties have been added, they can be displayed in the **Custom sensor properties** tab using user-configurable views which can contain a mix of standard and custom properties. You can edit the contents of custom properties (and the standard `comment` property) in the **Custom sensor properties** tab.

You can export data for selected sensors from a view, and import custom properties from external sources, in CSV format.

17.1 Creating Custom Sensor Properties

Use the `ubisense_ls_sensor_properties_admin` tool to add custom sensor properties.

You can download this tool using the Application Manager: go to the **DOWNLOADABLES** tab and open **Ubisense > Location system > Administration tools** to find it. See the DIMENSION4 Installation Guide for further information on downloading tools.

You can add properties of the following types:

- `bool`
- `choice`
- `double`
- `int`
- `string`
- `time`
- `timespan`

For each custom sensor property you want to add, run the `ubisense_ls_sensor_properties_admin` tool and specify the property type and description. For example to add a boolean property called `new`, use the command:

```
ubisense_ls_sensor_properties_admin create bool new
```

For properties of the type `choice`, you also specify the list of options. For example, the command:

```
ubisense_ls_sensor_properties_admin create choice color "Black" "White" "Grey"
```

creates a **color** property whose values can be black, white or grey.

If you create properties, you will need to restart any instances of LSC before you can see them.

17.2 Adding and Editing Views

You can choose properties for display, and the default order in which columns of data are shown, and save them as *views*. Before you can include custom sensor data in a view, you must have added the necessary properties to your dataset.

To create a view:

1. Click **Create new view** to display a list of columns available for inclusion in the view.
The list includes columns for properties supplied with your installation along with columns for any custom properties that have been defined.
2. Give the view a name.
3. Select columns for inclusion and click **Add >**.
 - Remove columns by selecting them in the selected columns list and clicking **< Remove**.
 - Select multiple columns by holding down Shift or Ctrl and clicking on them.
4. Select columns in the Selected columns list and use the **Move up** and **Move down** buttons to change the order in which they display.
5. When you are happy with your choices, click **Save**.

Editing a View

You can edit a view by selecting it from the **<Select a column view>** dropdown and clicking **Edit selected view**. Add and remove columns and change their display order as described above.

Deleting a View

To delete a view, select it from the **<Select a column view>** dropdown and click **Edit selected view**. Select **Delete view** and click **Save**.

17.3 Viewing Custom Sensor Properties

You choose how you want to display sensor information by choosing a view (see [Adding and Editing Views](#) on page 84 for information on defining the content of a view) and selecting the sensors you are interested in.

To display custom properties for selected sensors:

1. Open the **Custom sensor properties** tab.
A list of sensors is shown. This will either be all sensors, or a selection displayed using the **Show selected** button in this, or another, tab.

2. Choose a view from the **<Select a column view>** dropdown. The columns for properties included in the view are displayed.
 - You can change the order in which columns are displayed by dragging column headings. Save the new arrangement by clicking **Save column order** and this will become your default layout when you next select this view. (You can return to the predefined order of columns by clicking **Revert column order**.)
3. Refine the selection of rows by typing text to search for into **<Select matching rows>**—the search is case sensitive. All rows with matching text in any of the columns are highlighted.
 - Use the **Show groups** checkbox to toggle between a list of sensors and a tree view of sensor groups and sensors.
 - Sort on a column by clicking in its heading.

Editing Custom Properties

Custom properties, and the standard **Comment** property, are editable.

To edit a custom property, slowly double-click it and type in the field or choose from a dropdown of available values.

You can add identical information for multiple sensors: select the sensors, by holding down Shift or Ctrl and clicking, and then double-click one of your selections or press Enter to open the editor.

17.4 Importing Custom Sensor Properties

You can import custom property data for sensors from a CSV file. Before you can import custom sensor data, you must have added the necessary properties to your dataset.

The following constraints apply to importing custom sensor properties:

- The import process does not recognize sensors that are not already part of your dataset and does not import data associated with them
- Only custom properties and the standard **comment** property can have their values updated by the import; other properties are not changed

The CSV file must contain data formatted as comma-separated strings enclosed in quotation marks. The first row of the import file contains the names of the properties to be imported. It is important that the format is correct, as if the import process detects an incorrect format, the import will fail.

You must also take care to ensure that values supplied for custom properties are of the correct type. Otherwise, the import will fail.

To import custom sensor properties:

1. On the **Custom sensor properties** tab, click **Import rows**.
2. Type the name of the CSV file or browse to its location.

3. Decide how unknown data is handled:
 - Select **Ignore unknown properties** to allow the import process to ignore properties that are not configured in your dataset. If this is not selected, and unknown properties are encountered, the import will fail.
 - Select **Ignore unknown sensors** to allow the import process to skip data for sensors that do not belong to your dataset. If this is not selected, and unknown sensors are encountered, the import will fail.
4. Click **Import**.

17.5 Exporting Custom Sensor Properties

You can export a selection of custom sensor properties to a file in CSV format which can then be used in other applications.

To export custom sensor properties:

1. On the **Custom sensor properties** tab, display the sensors and properties to be exported. See [Viewing Custom Sensor Properties](#) on page 84.
2. Click **Export rows**.
3. Type the name of the file or browse to its location. Select **Overwrite existing file if necessary?** to replace a file that already exists.
4. Click **Export**.

DIMENSION4 support for GPS

Some DIMENSION4 tags contain GPS receivers and can periodically transmit their GPS coordinates via the tag's onboard 2.4 GHz radio.

From version 3.5 onwards, DIMENSION4 sensors can be configured to receive these transmissions and the DIMENSION4 support services can be configured to transform the GPS latitude/longitude values into tag position events in the user-defined XYZ coordinate system, so that the GPS readings create tag location events that are sent via the Ubisense OTW protocol or the ISO 24730 protocol exactly as though they were generated from UWB transmissions.

The DIMENSION4 support for GPS tags includes features to support:

- Configuring DIMENSION4 sensors to receive GPS signals from tags via the 2.4 GHz radio
- Creating and configuring GPS reference points using the Background objects tab in Location System Config
- Configuring tag type declarations to make best use of the tags' on-board tremble switches
- Viewing generated XYZ transformations of the tag GPS positions using the Event review tab in Location System Config
- Tracing the tag GPS protocol and XYZ transformation calculation using the Ubisense tracing features
- Configuring advanced parameters in the GPS processing chain

Support for the location of GPS tags by standard Ubisense sensors with radio capability replaces Ubisense's dedicated 2.4GHz Receivers which have been discontinued.


Sensors Equipped to Provide GPS Support

DIMENSION4 sensors that are equipped with a 2.4 GHz radio (model number D4SENSOR32IP30R) or that support an external antenna (model number D4DETECTOR32IP30) can be configured to receive GPS.

The sensor_health trace messages can be used to identify those sensors which have a radio installed and working. If the trace contains the section "|RADIO installed" then the sensor has a working radio; if the sensor has a section "|RADIO absent" then no radio is installed. See [DIMENSION4 trace messages](#) for further information.

18.1 Configuring DIMENSION4 sensors to receive GPS

To configure a DIMENSION4 sensor to receive GPS messages (and forward them to the calculation services), set the sensor's radio mode to 56, using the **Change sensor parameters / Radio / Mode** option, or the equivalent **Change all parameters / Sensor / Radio / Mode** option shown below:




By editing the 'Sensor / Radio Mode / Value 0' value on the same screen it is possible to set the receive frequency for the sensor. If the value is left at its default value of zero, the default Ubisense GPS tag frequency (of 2404000 kHz) will be used. Otherwise, the receive frequency in kHz should be used; for example, to use 802.15.4f-2012 channel 15, which is 2401750 kHz, enter 2401750 into the 'Sensor / Radio Mode / Value 0' parameter.

Note that, if the sensor supports an external antenna (as in part number D4DETECTOR32IP30), the radio mode does not need to be set in the configuration tool, because the sensor's internal radio mode will automatically be set to 56 by the sensor's on-board software. In this case, the value of the radio mode in the configuration tool will have no effect.

18.2 Creating and configuring GPS reference points


In order to transform a GPS reading into an XYZ reading it is necessary to define a mapping between the two co-ordinate systems. This is done by creating at least two GPS reference points, which have a position in the XYZ system and also have a latitude, longitude and altitude in the GPS system.

In the 'Add background objects' screen of Location System Config, a new 'reference object' type 'GPS reference point' is now available so that it is possible to drag GPS reference points onto the map.




The reference point is shown as a six-pointed gold 3D star. By double-clicking on the reference point, it is possible to configure its name and edit its position.

DIMENSION4 support for GPS



When a reference point has been added, its GPS parameters can be configured in the **Change all parameters** tab:



Three parameters are required:


- **Latitude Degrees North** is the decimal number of degrees north of the equator at the GPS reference point.
- **Longitude Degrees East** is the decimal number of degrees east of the Prime Meridian at the GPS reference point.
- **Metres Above Sea Level** is the elevation above sea level of the GPS reference point.

The first two parameters should be entered as accurately as possible. The elevation parameter can be significant in an area of high altitude (e.g. more than 1000 m above sea level) but will have little effect on the result for altitudes much below this.

18.3 Configuring tag type declarations


The GPS to XYZ transformation calculation makes use of the tag's tremble switch as a way of indicating that the tag is moving. But in some cases the tag's tremble switch will continue to be 'on' even when the tag is stationary (for example, if it is attached to a vehicle which will run its engine when stationary, generating enough vibration to activate the tremble switch).

In these cases it is possible to direct the calculation to ignore the tremble switch state by assigning a suitable type to the tag and using the 'Trembles When Stationary' attribute of the type to assert that the tag will still tremble even when stationary. This is set by setting the **Change all parameters / Tag Type / Trembles When Stationary** parameter:




18.4 Viewing generated XYZ positions of the tag

When a tag GPS reading is received by a sensor, it is forwarded to the 'Ubisense / Location system / Location sink' service in the location cell that owns the sensor. The service will then process the tag's GPS data, using the GPS reference points that were defined, to transform it into a XYZ data. This XYZ data is then logged to the logging services (if they are running) so that it can be viewed in the **Review location events** tab in Location System Config.



The position of the tag is displayed in grey (here it is in the leftmost column of parking spaces, about 8 m above the two cars).

This 'raw' XYZ data is then processed by a median filter in the service. Normally this will result in the generation of another location event, which is a valid tag XYZ reading to be sent out. This event is transmitted to clients using the Ubisense OTW protocol or the ISO 24730 protocol, and another event is also logged for viewing in the event review tab, in this case with the tag's location shown in red, indicating that this is a valid location:



18.5 Tracing the tag GPS protocol and calculation

18.5.0.1 The ls_sink_gps trace stream

The trace stream 'ls_sink_gps' will print a trace of processing events from the location sink's GPS processing. This is not intended to be enabled during GPS operation, but can be a useful aid to understanding the transformation from GPS to XYZ and debugging misconfigurations.

The trace stream messages cover the following events, which occur in sequence in the processing pipeline.

18.5.0.2 Message reception from the sensor

When the location sink service receives a message from the sensor it prints out its contents

```
ls sink gps:GPS message for <tag
id>:lat=<latitude>:long=<longitude>:alt=<altitude>:sx=<sensor
x>:sy=<sensor y>:sz=<sensor z>:seq=<sequence number>:gdop=<gps
gdop>:#jitter=<jitter count>:#sats=<number of receiving
satellites>:sbas=<gps sbas flag>:jitter=<tremble switch state>
```

18.5.0.3 Rejection of duplicate packets

Each sensor listens on two antennas, and multiple sensors may be listening for GPS packets, therefore a packet from an individual tag may result in several GPS packets being received at the location sink. The tag transmits a sequence number in each packet, and to ensure correct processing the location sink will record the sequence number of the last accepted GPS reading and then reject any subsequent packets that have the same sequence number for the given tag. When this happens it will print the message:

```
ls_sink_gps:ignoring duplicate data packet for <sequence number> from
<tag id>
```

18.5.0.4 Flushing filter state when the tag is moving

If the tag tremble switch is on and either the type of the tag is not set, or the type of the tag is set to a type that is asserted to not tremble when stationary (the default state for a tag type), then the processing will deduce that the tag is moving. The processing maintains some outlier rejection state that assumes that the tag is stationary, so when the tag is moving the state is not valid and must be deleted.

When this happens the location sink will print the message:

```
ls_sink_gps:flushing state and discarding data for <tag id> because
tremble_switch is on
```

18.5.0.5 Setting up the GPS-XYZ mapping using the reference points

Before processing its first tag event, and every 60 seconds thereafter, the location sink will update its GPS reference points. Two reference points are required in order to create a GPS-XYZ mapping, and if the service cannot find two reference points it will print this message:

```
warning: config error: we need 2 GPS reference points (only <0 or 1>
currently defined)
```

If two reference points are retrieved then the service will print out the points that it did get, together with the derived data that is used for building the mapping, as follows: the earth's radius (the mapping approximates to the Earth's oblate spheroid geometry by considering it as a sphere whose radius is determined by the latitude and altitude); the distance between the reference points calculated in the XYZ system and in the lat/long system (these values should be close together, and this is a useful check on the configuration); the bearings from one point to another in the XYZ system and in the lat/long system and thus the rotation between the two co-ordinate systems. The sequence of messages looks like this:

```
ls_sink_gps: got reference
points:1:<name>:<position><latitude>:<longitude>:<altitude>:2:
:<name>:<position>:<latitude>:<longitude>:<altitude>
ls_sink_gps: earth radius at latitude <mean latitude> = <radius of earth,
calculated from mean latitude and altitude>
ls_sink_gps: p1-p2 distance:<distance> (lat/long):<distance> (xy grid)
ls_sink_gps: p1-p2 bearing in XY system = <angle> degrees ls_sink_gps:
p1-p2 bearing in LL system = <angle> degrees
ls_sink_gps: rotation LL -> XY = <angle> degrees
```

Note that the mapping algorithm assumes that the latitude/longitude angle between the two reference points is small, so that the GPS coordinate system near the reference points can be approximated by a Cartesian system in which there is an XY plane which touches the earth's surface. If this is not possible then it is possible to define multiple mappings, with a different mapping for each Geometry cell. To do this, just place two reference points in each of the Geometry cells that require their own separate mapping – the location sink service will always prefer points that are physically inside its parent Geometry cell.

18.5.0.6 Rejecting the calculated XYZ if it is too far from the sensor

If the calculated position in the XYZ system is found to be so far from the receiving sensor that it would have been beyond the reception range of the sensor, then the reading is rejected as failing a sanity check. When this happens this message is printed:

```
ls_sink_gps: rejected GPS for <tag id> at <xyz position> (too far from receiving sensor at <xyz position of sensor>)
```

18.5.0.7 Filtering the reading using a median buffer

If the XYZ position has not been rejected by this stage, it is accepted as suitable for insertion into the filtering buffer, and this message is printed:

```
ls_sink_gps: accepted GPS for <tag id> at <xyz position>
```

This value is the same as the raw reading logged in the event review screen.

18.5.0.8 Extracting a median value for assertion

The outlier rejection filter uses a buffer of readings from which it selects the median value for assertion. The length of the buffer can be specified using the advanced parameters below.

When a suitable median value is selected then a location event is pushed into the clients (via the OTW or ISO 24730 protocols) and the asserted reading is logged in the event review screen, and this message is printed:

```
ls_sink_gps: injecting <tag id> at <position>
```

18.6 Enabling Clipping Regions with GPS Tag Positions

From version 3.6, a global configuration parameter `ls_gps_enable_clipping` enables clipping of GPS tag positions.

When this parameter is set, if a sensor forwards a GPS packet from a GPS tag, and that sensor is in one or more groups, then the forwarded packet will only result in a location event for the GPS tag if its derived position lies within the clipping region of one of the groups.

18.7 Configuring advanced parameters

There are some advanced parameters available to the location sink. These should not normally require changing but they may be changed by advanced users who have a clear understanding of the implications of their actions.

Parameter	Default value	Purpose
ls_gps_gdop	10.0	Not currently used. Do not modify.
ls_gps_stderr	10.0	The value to be used as the error estimate in meters when sending location events using the OTW protocol
ls_gps_range	300.0	The expected maximum range in meters at which a sensor can pick up a GPS tag transmission
ls_gps_buf_min	3	The minimum length of the median buffer (defaults to 3, must be > 1, and will be increased to the nearest odd number)
ls_gps_buf_max	11	The maximum length of the median buffer (defaults to 11, must be < 101, and will be increased to the nearest odd number)

Setting up DHCP Servers

Topic removed. Information on setting up DHCP servers is now available on the Ubisense Documentation Portal at [Setting Up DHCP Servers](#).

Configuring Battery Usage Monitoring

Topic removed. Information on managing tag batteries is now available on the Ubisense Documentation Portal at [Tag Types and Monitoring Tag Battery Usage](#).